

Where Automation Connects.



PLX82-EIP-PNC

Communication Gateway EtherNet/IP[™] Server to PROFINET Controller

October 17, 2025

Your Feedback Please

We always want you to feel that you made the right decision to use our products. If you have suggestions, comments, compliments or complaints about our products, documentation, or support, please write or call us.

How to Contact Us

ProSoft Technology, Inc. +1 (661) 716-5100 +1 (661) 716-5101 (Fax) www.prosoft-technology.com ps.support@belden.com

PLX82-EIP-PNC User Manual For Public Use.

October 17, 2025

ProSoft Technology®, is a registered copyright of ProSoft Technology, Inc. All other brand or product names are or may be trademarks of, and are used to identify products and services of, their respective owners.

Content Disclaimer

This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither ProSoft Technology nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. Information in this document including illustrations, specifications and dimensions may contain technical inaccuracies or typographical errors. ProSoft Technology makes no warranty or representation as to its accuracy and assumes no liability for and reserves the right to correct such inaccuracies or errors at any time without notice. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of ProSoft Technology. All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components. When devices are used for applications with technical safety requirements, the relevant instructions must be followed. Failure to use ProSoft Technology software or approved software with our hardware products may result in injury, harm, or improper operating results. Failure to observe this information can result in injury or equipment damage.

Copyright © 2025 ProSoft Technology, Inc. All Rights Reserved.



For professional users in the European Union

If you wish to discard electrical and electronic equipment (EEE), please contact your dealer or supplier for further information.



Warning - Cancer and Reproductive Harm - www.P65Warnings.ca.gov

Agency Approvals and Certifications

Please visit our website: www.prosoft-technology.com

ProSoft Technology, Inc. Page 2 of 150

Contents

	Your Feedback	k Please	2
	How to Contac	t Us	2
	Content Discla	imer	2
	Agency Approv	vals and Certifications	2
	0 ,		
	04 4 11		_
1	Start Here		
	1.1	PLX82-EIP-PNC Overview	e
	1.2	System Requirements	
	1.3	Shipping Contents	
	1.4	11 0	
		Setting Jumpers	
	1.5		
	1.6	Connecting Power	T1
2	ProSoft C	onfiguration Builder Software	12
_	11000110		
	2.1	Creating a New Project	12
	2.2	Setting a Project Name	15
	2.3	Setting a Temporary IP Address	16
	2.4	Ethernet Configuration	19
	2.5	Saving the Project	
	2.6	Downloading the Configuration File to the PLX82-EIP-PNC	
	2.7	Uploading a Configuration from the PLX82-EIP-PNC	
	2.8	Exporting a Project	
	2.9	Writing the Project to Compact Flash	
	2.0	Witting the Froject to Compact Hash	20
3	Configurii	ng the EtherNet/IP Driver	26
	2.4		
	3.1	RSLogix 5000	
	3.2	Adding an Ethernet Bridge	
	3.3	Adding the PLX82-EIP-PNC	
	3.4	Importing the Ladder Rung	33
	3.5	Downloading the RSLogix 5000 Project to the Processor	36
	3.6	EIP Class 3 Server Connection	
	3.7	EIP Class 1 Connection	
	3.8	EIP Class 3 Client/UClient [x] Connection	40
	3.8.1	EIP Class 3 Client/UClient [x]	40
	3.8.2	EIP Class 3 Client/UClient [x] Commands	
	3.9	Configuring the EIP Processor Path	48
	Canfigural	ng the DDOCINET Controller	E
4	Configuri	ng the PROFINET Controller	50
	4.1	Importing GSD Files	53
	4.2	Adding a Slave Device to the Project	
	4.3	Configuring a Slave Device	
	4.4	Verifying Slave Device Information	
	4.4.1	Controller Network Settings	
		· · · · · · · · · · · · · · · · · · ·	
	4.4.2	Device Table	
	4.4.3 4.4.4	IP Address Table	
	111	Process Data	6/

	4.4.5	Address Table	65
	4.4.6	FSU-/Port-Settings	68
	4.4.7	Stations Timing	69
	4.4.8	Controller Settings	70
	4.4.9	Ethernet Devices	
	4.4.10	Viewing Configured Device Information	78
5	PROFIN	IET Start Input and Output Byte Offsets	81
6	Acyclic	Data	82
7	Commo	nNet Data Map	85
8	Webpag	je	87
9	Diagnos	stics and Troubleshooting	89
	9.1	LEDs	89
	9.2	PCB Diagnostics	
	9.2.1	PCB Diagnostics Menu Options	
	9.2.2	PROFINET General Status Codes	
	9.2.3	PROFINET Device Errors	
	9.2.4	Acyclic Read/Write Communication Status	
	9.2.5	Acyclic Read/Write PNIO Remote Procedure Call Status	
	9.3	Network Diagnostics	
	9.3.1	Establishing a Diagnostic Connection	
	9.3.2	General Diagnosis	111
	9.3.3	Master Diagnosis	112
	9.3.4	Station Diagnosis	
	9.3.5	Firmware Diagnosis	114
	9.3.6	Extended Diagnosis	115
	9.3.7	Tools	126
	9.3.8	Viewing Alarm Information	133
	9.3.9	EIP Status Data in Upper Memory	134
	9.3.10	EIP Error Codes	137
	9.3.11	PNC Status Data in Upper Memory	142
10	Referen	се	146
	10.1	EtherNet/IP Explicit Messaging Server Command Support	
	10.2	Accessing the PLX82-EIP-PNC Internal Memory	
	10.2.1	MSG Instruction Type - CIP	
	10.2.2	MSG Instruction Type - PCCC	
	10.3	Specifications	
	10.3.1	Hardware Specifications	
	10.3.2	EtherNet/IP (EIP) Specifications	
	10.3.3	PROFINET (PNC) Specifications	149

11	Support, Service & Warranty		
11	.1	Contacting Technical Support	. 150
11	2	Warranty Information	150

ProSoft Technology, Inc.


1 Start Here

1.1 PLX82-EIP-PNC Overview


The EtherNet/IP™ to PROFINET Controller gateway provides EtherNet/IP-based controllers the ability to control up to 36 PROFINET RT devices such as field I/O, drives, HMIs, controllers, etc.

The PLX82-EIP-PNC is a stand-alone DIN-rail mounted unit that provides two Ethernet ports for communications, remote configuration, and diagnostics. The onboard SD card slot (SD card optional) is used for storing configuration files that can be used for recovery, transferring the configuration to another gateway, or general configuration backup.

The gateway supports 248 words of input data and 248 words of output data per Class 1 connection. The module supports 8 EIP connections and 100 Class 3 EIP commands. The gateway is configured using *ProSoft Configuration Builder (PCB)* and *ProSoft fdt Configuration Manager*.



ProSoft Technology, Inc. Page 6 of 150



- ODVA Approved
- PROFINET v2 certification with PROFINET Class A compliance
- EtherNet/IP and PROFINET certifications ensure that the device is compatible with their respective network
- Field-tested with multiple PROFINET devices from multiple vendors
- Remotely view and diagnose EtherNet/IP and PROFINET networks
- Embedded EDS AOP provided to allow for seamless integration to Studio 5000 and RSLogix 5000
- No ladder programming is required using EtherNet/IP I/O connections
- PLX82-EIP-PNC gateways with firmware version v1.006 and above support the Link Layer Discovery Protocol (LLDP)

ProSoft Technology, Inc. Page 7 of 150

1.2 System Requirements

The PLX82-EIP-PNC module requires the following minimum hardware and software components:

- Rockwell Automation ControlLogix or CompactLogix processor (firmware version 10 or higher).
- Rockwell Automation RSLogix 5000 programming software version 16 or higher
- Rockwell Automation RSLinx[®] communication software version 2.51 or higher.

Supported operating systems:

- Microsoft Windows 10
- Microsoft Windows 7 Professional (32-or 64-bit)
- Microsoft Windows 2000 Professional with Service Pack 1, 2, or 3
- Microsoft Windows Server 2003

ProSoft fdt Configuration Manager software requirements:

- Microsoft .NET must be installed on the PC or laptop used to configure the gateway.
- 2 GHz minimum processor

Supported operating systems:

- Microsoft Windows 11
- Microsoft Windows 10
- Microsoft Windows 8

1.3 Shipping Contents

The following components are included with the PLX82-EIP-PNC.

Qty.	Part Name	Part Number	Part Description
1	EtherNet/IP™	PLX82-EIP-PNC	ProSoft communication gateway
	Server to		
	PROFINET		
	Controller		
1	Screwdriver	HRD250	Small, flat-bladed screwdriver
1	Power Connector	J180	3-wire DC power connector

If any of these components are missing, please contact ProSoft Technology Technical Support for replacement parts.


ProSoft Technology, Inc. Page 8 of 150

1.4 Setting Jumpers


The jumper settings are located on the back of the PLX82-EIP-PNC. For security reasons, the *Mode 1* and *Mode 2* jumpers are not readily accessible. Under normal conditions, these two jumpers will not be required.

Setup Jumper

Mode 3 is jumpered by default. It is only required for firmware updates.



1.5 Mounting the PLX82-EIP-PNC on a DIN-rail



- 1 Position the PLX82-EIP-PNC on the DIN-rail B at a slight angle.
- 2 Hook the lip on the rear of the adapter onto the top of the DIN-rail, and rotate the adapter onto the rail.
- **3** Press the adapter down onto the DIN-rail until flush. The locking tab snaps into position and locks the module to the DIN-rail.
- 4 If the adapter does not lock in place, use a screwdriver or similar device to move the locking tab down while pressing the adapter flush onto the DIN-rail and release the locking tab to lock the adapter in place. If necessary, push up on the locking tab to lock.

1.6 Connecting Power



Use the J180 Power Connector to connect to the proper signals.

WARNING: Be sure not to reverse polarity when applying power to the PLX82-EIP-PNC. This causes permanent damage to the internal power distribution circuits.


2 ProSoft Configuration Builder Software

ProSoft Configuration Builder (PCB) and ProSoft fdt Configuration Manager is used to configure the PLX82-EIP-PNC. The software files can be downloaded at: www.prosoft-technology.com.


Note: To use the ProSoft Configuration Builder under the Windows 7 OS, you must be sure to install it using the *Run as Administrator* option. To find this option, right-click the Setup.exe program icon, and then click **RUN AS ADMINISTRATOR** on the context menu. You must install using this option even if you are already logged in as an Administrator on your network or personal computer (PC). Using the Run as Administrator option allows the installation program to create folders and files on your PC with proper permissions and security. If you do not use the Run as Administrator option, the ProSoft Configuration Builder may appear to be installed correctly, but you will receive multiple file access errors whenever the ProSoft Configuration Builder is running, especially when changing configuration screens. If this happens, you must completely uninstall the ProSoft Configuration Builder and then re-install using the Run as Administrator option to eliminate the errors.

Note: The ProSoft fdt Configuration Manager software requires Microsoft.NET to be installed on the PC/laptop used to configure the module. The PC/laptop must have a 2 GHz minimum processor.


2.1 Creating a New Project




- 1 From your PC, click START > PROSOFT TECHNOLOGY > PROSOFT CONFIGURATION BUILDER.
- 2 Click **FILE > NEW**. The application prompts for a *Module Type*.



3 Select the PLX80 radio button and then select PLX82-EIP-PNC.




4 Click **OK**. The PLX82-EIP-PNC is now added to ProSoft Configuration builder.




2.2 Setting a Project Name

The project name is initially set to "Default Location".

1 Right click on the **DEFAULT LOCATION** icon and select **RENAME**.



2 Type in a name for your project and press **ENTER**.




2.3 Setting a Temporary IP Address

Important: ProSoft Discovery Service (PDS) is a built-in utility within PCB. It locates the PLX82-EIP-PNC through UDP broadcast messages. These messages may be blocked by routers or layer 3 switches. In that case, PDS is unable to locate the PLX82-EIP-PNC.

To use PDS, arrange the Ethernet connection so that there is no router or layer 3 switch between the computer and the PLX82-EIP-PNC, or reconfigure the router or layer 3 switch to allow the routing of the UDP broadcast messages.


1 Right-click the PLX82-EIP-PNC icon and select DIAGNOSTICS.




2 When the *Diagnostics* dialog opens, click on the **SETUP CONNECTION** icon.




3 When the *Connection Setup* dialog opens, click the **BROWSE DEVICES** button to locate your device.




4 This launches *Prosoft Discovery Service*, which displays the ProSoft modules that have been detected on the network



5 Right-click the module, and then click ASSIGN TEMPORARY IP.




6 The module's default IP address is 192.168.0.250.




7 Enter an unused IP within your subnet, and then click **OK**.

2.4 Ethernet Configuration

This is used to provide address information for the gateway; in this case, the EIP driver. This is unique address information for the PLX82-EIP-PNC's EIP driver and diagnostic interface. The default is initially set to 192.168.0.250.





- 1 Select **my_ip** and enter the IP address of the EIP device in the gateway.
- 2 Select netmask and enter the network mask.
- **3** If using a gateway/router, select **gateway** and enter the IP address of the network gateway (router). If you are not using a gateway/router, enter 0.0.0.0 in this field.
- 4 Click **OK** when done.

Parameter	Description
my_ip	This is the default address assigned to the EIP side of the gateway. Change
	this to the address that suits your network configuration.
netmask	This is the default network mask. Update this to the appropriate network mask.
gateway	This is the IP address for gateway that you want to use.


2.5 Saving the Project

The PCB project must be saved when you move from PCB to ProSoft fdt Configuration Manager if you have not previously saved the project while in PCB.


- 1 Navigate to FILE > SAVE As.
- 2 Select the appropriate directory and filename name of your ProSoft Project File (PPF).
- Click SAVE.

2.6 Downloading the Configuration File to the PLX82-EIP-PNC


After you have created the project in the ProSoft Configuration Builder and configured the PROFINET controller (Chapter 4, page 50) in ProSoft fdt Configuration Manager software, you are ready to download it to the PLX82-EIP-PNC.



1 From PCB, right-click on the PLX82-EIP-PNC icon and select DOWNLOAD FROM PC TO DEVICE.



2 The *Download files from PC to module* dialog box opens:



3 Click Test Connection.

If the PLX82-EIP-PNC's IP address matches the address in the Configuration Manager, and the software displays the following message: "Successfully connected."

If the PLX82-EIP-PNC's IP address does not match what was entered in ProSoft Configuration Builder, then the software displays an error message: "Error: Connecting to Module. Please check your IP Address."

4 Click **DOWNLOAD** to download the project to the PLX82-EIP-PNC.


2.7 Uploading a Configuration from the PLX82-EIP-PNC

Use this feature to retrieve the configuration from the PLX82-EIP-PNC. Not only does it retrieve the configuration, but is also retrieves all related files used in creating that configuration. There are several reasons that you might use this feature:

- You want to modify the configuration, but do not have access to the original configuration files.
- You want to copy a configuration from one PLX82-EIP-PNC to another PLX82-EIP-PNC.
- You want to back up the configuration for safety.

Warning: This function replaces the current configuration in the ProSoft Configuration Builder with the one from the PLX82-EIP-PNC. Make sure you save the current configuration before uploading the configuration from the PLX82-EIP-PNC.

- Optional: Create a new project in the ProSoft Configuration Builder by choosing FILE > NFW
- 2 Right-click the PLX82-EIP-PNC icon and choose UPLOAD FROM DEVICE TO PC.



3 The *Upload files from Module to PC* dialog box opens:



- 4 Select the *Connection Type*. If you don't know the IP address of the module that contains the configuration that you want, you can browse devices using the **Browse Device(s)** button. This launches the ProSoft Discovery Service application.
- **5** Enter the IP address of the PLX82-EIP-PNC. All PLX82-EIP-PNC's are shipped with a default IP address **192.168.0.250**. Click the **USE DEFAULT IP** button to use the default address.
- **6** Use the **TEST CONNECTION** button to ensure that the connection is good.
- 7 Click the **UPLOAD** button to start the upload.
- **8** When the upload is complete, the configuration is displayed in PCB. You can edit or save it on the PC.

2.8 Exporting a Project


You can export a PCB file that was created on your PC. This allows someone on a different PC to import your configuration file and have all the files that are part of your project. If you need assistance from ProSoft Technology Technical Support, they will need your exported files.

- 1 In the ProSoft Configuration Builder choose **PROJECT > MODULE > EXPORT CONFIGURATION FILES**.
- 2 In the Save As dialog box, navigate to the correct directory and save the configuration file.

2.9 Writing the Project to Compact Flash

This procedure describes how to save a project from a PC to a Compact Flash drive.

1 From PCB, navigate to **Project > Module > Write to Compact Flash**.




2 Choose the appropriate drive, then click **NEXT**.




3 Follow the on-screen instructions and click **FINISH** when complete.

3 Configuring the EtherNet/IP Driver




3.1 RSLogix 5000

If you want to add the PLX82-EIP-PNC gateway to an existing project, skip to *Adding an Ethernet Bridge* (page 28).




To create a new project...


- 1 In RSLogix 5000, choose FILE > NEW.
- 2 Select your PLC.
- 3 Select **REVISION 16** or newer.
- 4 Enter a name for your controller, such as MY_CONTROLLER.
- 5 Select your chassis type and click **OK**.



3.2 Adding an Ethernet Bridge




1 Expand the I/O CONFIGURATION folder in the Project tree. Right-click the appropriate communications bus and choose **NEW MODULE**.



2 This opens the Select Module Type dialog box.


3 For this example, click the 1756-ENBT ETHERNET BRIDGE and then click CREATE.




4 Enter the name, revision, and IP address for the 1756-ENBT and then click **OK**.




3.3 Adding the PLX82-EIP-PNC




1 In RSLogix 5000, under the *1756-ENBT* icon, right-click **ETHERNET** and then choose **New Module**.



2 Select the GENERIC ETHERNET/IP CIP BRIDGE and then click CREATE.




3 Enter the name and IP address for the gateway and then click **OK**.




4 Under the gateway (PLX82_EIP_PNC in this example), right-click **CIP Bus** and then choose **New Module**.




5 Click the GENERIC CIP MODULE and then click CREATE.




Add a Class 1 connection (enter the name and configuration parameters). Enter the Name, select **DATA-INT** for *Comm Format*, and enter the *Connection Parameters* as shown below. Click **OK**.



7 Right-click the new connection and then choose **PROPERTIES**.




8 On the *Connection* tab, enter the *Requested Packet Interval (RPI)* time and then click **OK**.




3.4 Importing the Ladder Rung

Note: The Add-On Instruction is only needed when Alarming and Acyclic Messaging are required. "Alarming" should not be confused with status information, as device and network status is available when the AOI is used or not.


- 1 Download the .L5X file from the PLX82-EIP-PNC product page at www.prosoft-technology.com.
- 2 Open the Main Routine.
- 3 Right-click on an existing rung and select **IMPORT RUNGS**.




4 At the *Input Rungs* dialog, locate the directory that contains the Add On rung.



- 5 Click IMPORT.
- 6 In the *Import Configuration* dialog box, make sure the *Operation* is set to **CREATE**, and then click **OK**.




7 When the import completes, the Add-On Instruction appears under *Add-On Instructions* in the window.



3.5 Downloading the RSLogix 5000 Project to the Processor

- 1 Save, and then download the project to the processor.
- 2 A yellow triangle in RSLogix 5000 means an error on connection. Check that the OUTPUT size and INPUT size for the Class 1 connection in the gateway configuration matches and the COMM FORMAT is INT. Try increasing the REQUESTED PACKET INTERVAL time of module if the error persists.
- 3 Check the PLX82-EIP-PNC's IP address. This is located in the bottom left of the *Diagnostics* page.
- 4 If errors persist, download the configuration again to make sure that the module configuration matches the configured RSLogix 5000 program.
- 5 For additional troubleshooting, use the ProSoft Configuration Builder. Click on PROJECT > MODULE > DIAGNOSTICS.

Class 1 displays the connection RPI time of processor and the IP address of the module. The open connection count starts at 1 and increments if the connection to the processor is interrupted or there is a connection timeout. State, open connection, and connection timeout are controlled by the code.




You can change the RPI and Ethernet IP in the ladder configuration in RSLogix 5000 (right-click **CONNECTION**1 and choose **PROPERTIES**).

3.6 EIP Class 3 Server Connection

Use the EIP Class 3 Server connection in ProSoft Configuration Builder when the gateway is acting as a server (slave) device responding to message instructions initiated from a client (Controller) device such as an HMI, DCS, PLC, or PAC.

- 1 Within ProSoft Configuration Builder, click the [+] next to the gateway, then click the [+] next to EIP Class 3 Server.
- 2 Double-click the second EIP CLASS 3 SERVER to display the Edit EIP Class 3 Server dialog box.



- 3 Select the Server File Size (100 or 1000).
 - For a value of 100, the registers are from N10:0 to N10:99.
 - For a value of 1000, the valid registers are from N10:0 to N10:999.


3.7 EIP Class 1 Connection

The EIP Class 1 connection is used with the gateway and acts as an EtherNet/IP adapter transferring data to and from a PLC using a direct I/O connection. Direct I/O connections can be used to transfer large amounts of data quickly.


The EIP driver can handle up to eight I/O connections, each with 248 words of input data and 248 words of output data. Rockwell Automation customers running RSLogix 5000 v2.0 or higher can take advantage of premier integration with an Add-on profile.

After you create the PLX82-EIP-PNC in RSLogix 5000, you must configure gateway connections.

1 In ProSoft Configuration Builder, click the [+] next to the gateway, and then click the [+] next to EIP Class 1 Connection [x].



2 Double-click the **EIP CLASS 1 CONNECTION [X]** to display the *Edit - EIP Class 1 Connection [x]* dialog box.



3 In the dialog box, enter a value for each parameter.

Parameter	Value	Description
Input Data Address	0 to 9999	This parameter specifies the starting address within the gateway's virtual database for data transferred from the
		PLC to the module.
Input size	0 to 248	This parameter specifies the number of integers being transferred to the PLC's input image (248 integers max).
Output data address	0 to 9999	This parameter specifies the starting address within the gateway's virtual database for data transferred from the gateway to the PLC.
Output size	0 to 248	This parameter specifies the number of integers being transferred to the PLC's output image (248 integers max).

Create entries for up to 8 connections by following the same steps.

3.8 EIP Class 3 Client/UClient [x] Connection

EIP Class 3 Client [x] connections are used when the gateway is acting as a client/controller initiating message instructions to the server/slave devices. The EIP driver supports three connected clients. Typical applications include SCADA systems, PLC and SLC communication.

The EIP driver supports one unconnected client connection. Unconnected messaging is a type of EtherNet/IP explicit messaging that uses TCP/IP implementation. Certain devices, such as the AB Power Monitor 3000 series B, support unconnected messaging. Check your device documentation for further information about its EtherNet/IP implementation.

3.8.1 EIP Class 3 Client/UClient [x]

- 1 In ProSoft Configuration Builder, click the [+] next to the gateway, then click the [+] next to EIP Class 3 Client [x] or EIP Class 3 UClient [x].
- 2 Double-click the second *EIP Class 3 Client [x]* to display the *Edit EIP Class 3 Client [x]* dialog box.
- 3 Click a parameter to change it's value.

The following table specifies the configuration for the EIP client (Controller) device on the network port:

Parameter	Value	Description
Minimum Command Delay	0 to 65535 milliseconds	Specifies the number of milliseconds to wait between the initial issuances of a command. This parameter can be used to delay all commands sent to servers to avoid "flooding" commands on the network. This parameter does not affect retries of a command as they will be issued when a failure is recognized.
Response Timeout	1 to 65535 milliseconds	Specifies the amount of time in milliseconds that a client will wait before re-transmitting a command if no response is received from the addressed server. The value depends on the type of communication network used, and the expected response time of the slowest device connected to the network.
Retry Count	0 to 10	Specifies the number of times a command will be retried if it fails.

3.8.2 EIP Class 3 Client/UClient [x] Commands

- There is a separate command list for each of the different message types supported by the protocol. Each list is processed from top to bottom, one after the other, until all specified commands are completed, and then the polling process begins all over again.
- This section defines the EtherNet/IP commands to be issued from the gateway to server devices on the network. These commands can be used for data collection and/or control of devices on the TCP/IP network.
- In order to interface the virtual database with Rockwell Automation Programmable Automation controllers (PACs), Programmable Logic Controllers (PLCs), or other EtherNet/IP server devices, you must construct a command list using the command list parameters for each message type.

To add Class 3 Client/UClient [x] commands...

- 1 In ProSoft Configuration Builder, click the [+] next to the gateway, the click the [+] next to EIP Class 3 Client [x] or EIP Class 3 UClient [x].
- 2 Double-click the desired command type to display the *Edit EIP Class 3 Client [x] Commands* or *Edit EIP Class 3 UClient Commands* dialog box.
- 3 Click ADD Row to add a new command.
- **4** Click **EDIT Row** or double-click the row to display the *Edit* dialog box where you configure the command.

ProSoft Technology, Inc. Page 41 of 150

Page 42 of 150

Class 3 Client/UClient [x] Commands SLC500 2 Address Fields

Parameter	Value	Description
Enable	Enable	Specifies if the command should be executed and under what
	Disable	conditions.
	Conditional Write	Enable - The command is executing each scan of the command list.
		Disable - The command is disabled and will not be executed.
		Conditional Write - The command executes only if the internal
		data associated with the command changes.
Internal Address	0 to 9999	Specifies the database address in the module's internal
		database to be associated with the command. If the command
		is a read function, the data received in the response message is
		placed at the specified location. If the command is a write
		function, data used in the command is sourced from a specified
		data area.
Poll Interval	0 to 65535	Specifies the minimum interval to execute continuous
		commands. The parameter is entered in 1/10 of a second. If a
		value of 100 is entered for a command the command executes
Reg Count	1 to 125	no more frequently that every 10 seconds. Specifies the number of data points to be read from or written to
Reg Count	1 10 123	the target audience.
Swap Code	None	Specifies if the data from the server is to be ordered differently
Cwap Codo	Word Swap	than it was received. This parameter is typically used when
	Word and Byte	dealing with floating-point or other multi-register values.
	Swap	None - No change is made (abcd)
	Byte Swap	Word Swap - The words are swapped (cdab)
	, ,	Word and Byte Swap - The words and bytes are swapped (dcba)
		Byte Swap - The bytes are swapped (badc).
IP Address	XXX.XXX.XXX	Specifies the IP address of the target device to be addressed by
		this command.
Slot	-1	Use a value of -1 when interfacing to an SLC 5/05. These
		devices do not have a slot parameter. When addressing a
		processor in a ControlLogix or CompactLogix rack, the slot
		number corresponds to the slot in the rack containing the
Tura Cada	E04	controller being addressed.
Func Code	501 509	Specifies the function code to be used in the command.
	309	501 - Protected Typed Read 509 - Protected Typed Write
File Type	Binary	Specifies the file type to be associated with the command.
The Type	Counter	openies the file type to be associated with the command.
	Timer	
	Control	
	Integer	
	Float	
	ASCII	
	String	
	Status	
File Number	-1	Specifies the PLC-5 file number to be associated with the
		command. If a value of -1 is entered, the field will not be used in the command, and the default file will be used.
Element Number		Specifies the element in the file where the command will start.
Comment		This field can be used to give a 32-character comment to the
		command.

Class 3 Client/UClient [x] Commands SLC500 3 Address Fields

Parameter	Value	Description
Enable	Enable	Specifies if the command should be executed and under what
	Disable	conditions.
	Conditional Write	Enable - The command is execute each scan of the command list.
		Disable - The command is disabled and will not be executed.
		Conditional Write - The command executes only if the internal data
		associated with the command changes.
Internal	0 to 9999	Specifies the database address in the module's internal database to
Address		be associated with the command. If the command is a read function,
		the data received in the response message is placed at the specified
		location. If the command is a write function, data used in the
		command is sourced from a specified data area.
Poll Interval	0 to 65535	Specifies the minimum interval to execute continuous commands.
		The parameter is entered in 1/10 of a second. If a value of 100 is
		entered for a command the command executes no more frequently
		that every 10 seconds.
Reg Count	1 to 125	Specifies the number of data points to be read from or written to the
		target device.
Swap Code	None	Specifies if the data from the server is to be ordered differently than
	Word Swap	it was received. This parameter is typically used when dealing with
	Word and Byte	floating-point or other multi-register values.
	Swap	None - No change is made (abcd)
	Byte Swap	Word Swap - The words are swapped (cdab)
		Word and Byte Swap - The words and bytes are swapped (dcba)
		Byte Swap - The bytes are swapped (badc).
IP Address	XXX.XXX.XXX	Specifies the IP address of the target device to be addressed.
Slot	-1	Use a value of -1 when interfacing to an SLC 5/05. These devices do
		not have a slot parameter. When addressing a processor in a
		ControlLogix or CompactLogix rack, the slot number corresponds to
		the slot in the rack containing the controller being addressed.
Func Code	502	Specifies the function code to be used in the command.
	510	502 - Protected Typed Read
	511	510 - Protected Typed Write
		511 - Protect Typed Write w/Mask
File Type	Binary	Specifies the file type to be associated with the command.
	Counter	
	Timer	
	Control	
	Integer	
	Float	
	ASCII	
	String	
	Status	
File Number	-1	Specifies the PLC-5 file number to be associated with the command.
		If a value of -1 is entered for the parameter, the field will not be used
		in the command, and the default file will be used.
Element		Specifies the element in the file where the command will start.
Number		
Sub-Element		Specifies the sub-element to be used with the command. Refer to
		the AB documentation for a list of valid sub-element codes.
Comment		This field can be used to give a 32-character comment to the

Class 3 Client/UClient [x] Commands PLC5 Binary

Parameter	Value	Description
Enable	Enable	Specifies if the command should be executed and under what
	Disable	conditions.
	Conditional Write	Enable - The command is executed each scan of the command list.
		Disable - The command is disabled and will not be executed.
		Conditional Write - The command executes only if the internal data
		associated with the command changes.
Internal	0 to 9999	Specifies the database address in the module's internal database to
Address		be associated with the command. If the command is a read function,
		the data received in the response message is placed at the specified
		location. If the command is a write function, data used in the
		command is sourced from a specified data area.
Poll Interval	0 to 65535	Specifies the minimum interval to execute continuous commands.
		The parameter is entered in 1/10 of a second. If a value of 100 is
		entered for a command the command executes no more frequently
		that every 10 seconds.
Reg Count	1 to 125	Specifies the number of data points to be read from or written to the
		target device.
Swap Code	None	Specifies if the data from the server is to be ordered differently than
	Word Swap	it was received. This parameter is typically used when dealing with
	Word and Byte	floating-point or other multi-register values.
	Swap	None - No change is made (abcd)
	Byte Swap	Word Swap - The words are swapped (cdab)
		Word and Byte Swap - The words and bytes are swapped (dcba)
		Byte Swap - The bytes are swapped (badc).
IP Address	XXX.XXX.XXX	Specifies the IP address of the target device to be addressed by this
		command.
Slot	-1	Use a value of -1 when interfacing to an SLC 5/05. These devices do
		not have a slot parameter. When addressing a processor in a
		ControlLogix or CompactLogix rack, the slot number corresponds to
		the slot in the rack containing the controller being addressed.
Func Code	100	Specifies the function code to be used in the command.
	101	100 - Word Range Write
	102	101 - Word Range Read
		102 - Read-Modify-Write
File Type	Binary	Specifies the file type to be associated with the command.
	Counter	
	Timer	
	Control	
	Integer	
	Float	
	ASCII	
	String	
	Status	0 15 4 810.551
File Number	-1	Specifies the PLC-5 file number to be associated with the command.
		If a value of -1 is entered for the parameter, the field will not be used
		in the command, and the default file will be used.
Element Number		Specifies the element in the file where the command will start.
		Chariffica the sub-element to be used with the comment D. C.
Sub-Element		Specifies the sub-element to be used with the command. Refer to
Comment		the AB documentation for a list of valid sub-element codes.
Comment		This field can be used to give a 32-character comment to the
		command.

Class 3 Client/UClient [x] Commands PLC5 ASCII

Enable Disable conditions. Conditional Write ENABLE - The Command is executed each scan of the command list DISABLE- The command is disabled and will not be executed CONDITIONAL WRITE - The Command executes only if the internal data associated with the command changes Internal O to 9999 Specifies the database address in the modules internal database to be associated with the command. If the command is a read function, the data received in the response message is placed at the specified location. If the command is a write function data used in the command is sourced from specified location.
Conditional Write ENABLE - The Command is executed each scan of the command list DISABLE- The command is disabled and will not be executed CONDITIONAL WRITE - The Command executes only if the internal data associated with the command changes Internal O to 9999 Specifies the database address in the modules internal database to be associated with the command. If the command is a read function, the data received in the response message is placed at the specified location. If the command is a write function data used in the
DISABLE- The command is disabled and will not be executed CONDITIONAL WRITE - The Command executes only if the internal data associated with the command changes Internal 0 to 9999 Specifies the database address in the modules internal database to be associated with the command. If the command is a read function, the data received in the response message is placed at the specified location. If the command is a write function data used in the
CONDITIONAL WRITE - The Command executes only if the internal data associated with the command changes Internal 0 to 9999 Specifies the database address in the modules internal database to be associated with the command. If the command is a read function, the data received in the response message is placed at the specified location. If the command is a write function data used in the
associated with the command changes Internal 0 to 9999 Specifies the database address in the modules internal database to be associated with the command. If the command is a read function, the data received in the response message is placed at the specified location. If the command is a write function data used in the
Internal 0 to 9999 Specifies the database address in the modules internal database to be associated with the command. If the command is a read function, the data received in the response message is placed at the specified location. If the command is a write function data used in the
Address be associated with the command. If the command is a read function, the data received in the response message is placed at the specified location. If the command is a write function data used in the
the data received in the response message is placed at the specified location. If the command is a write function data used in the
location. If the command is a write function data used in the
command is sourced from specified location.
comment to control them absolute to control
Poll Interval 0 to 65535 Specifies the minimum interval to execute continuous commands.
The parameter is entered in 1/10 of a second. If a value of 100 is
entered for a command the command executes no more frequently
than every 10 seconds.
Reg Count 1 to 125 Specifies the number of data points to be read from or written to the
target device.
Swap Code None Specifies if the data from the server is to be ordered differently than
Word swap it was received. This parameter is typically used when dealing with
Word and Byte floating-point or other multi-register values.
swap None - No change is made (abcd)
Byte swap Word swap - The words are swapped (cdab)
WORD AND BYTE SWAP - The words and bytes are swapped (dcba)
Byte swap - The bytes are swapped (badc)
IP Address xxx.xxx.xxx Specifies IP address of the target device to be addressed by this
command
Slot -1 Specifies the slot number for the device. Use a value of -1 when
interfacing to a PLC5 These devices do not have a slot parameter.
When addressing a processor in a ControlLogix or CompactLogix,
the slot number corresponds to the slot in the rack containing the
controller being addressed.
Func Code 150 Specifies the function code to be used in the command.
151 150 - Word Range Write
152 151 - Word Range Read
152 - Read-Modify-Write
File String Specifies the PLC-5 Address as a string. For example, N10:300
Comment Optional 32-character comment for the command.

Class 3 Client/UClient [x] Commands Controller Tag Access


Parameter	Value	Description
Enable	Enable	Specifies if the command should be executed and under
	Disable	what conditions.
	Conditional Write	ENABLE - The Command is executed each scan of the
		command list
		DISABLE- The command is disabled and will not be executed
		CONDITIONAL WRITE - The Command executes only if the internal
		data associated with the command changes
Internal	0 to 9999	Specifies the database address in the modules internal
Address		database to be associated with the command. If the
		command is a read function, the data received in the
		response message is placed at the specified location. If the
		command is a write function data used in the command is
		sourced from the specified location.
Poll Interval	0 to 65535	Specifies the minimum interval to execute continuous
		commands. The parameter is entered in 1/10 of a second. If
		a value of 100 is entered for a command the command
		executes no more frequently than every 10 seconds.
Reg Count	1 to 125	Specifies the number of data points to be read from or written
J		to the target device.
Swap Code	None	Specifies if the data from the server is to be ordered
•	Word swap	differently than it was received. This parameter is typically
	Word and Byte	used when dealing with floating-point or other multi-register
	swap	values.
	Byte swap	None - No change is made (abcd)
	, ,	WORD SWAP - The words are swapped (cdab)
		WORD AND BYTE SWAP - The words and bytes are swapped (dcba)
		BYTE SWAP - The bytes are swapped (badc)
IP Address	XXX.XXX.XXX	Specifies the IP address of the target device to be addressed
		by this command
Slot	-1	Specifies the slot number for the device. Use a value of -1
		when interfacing to a PLC5 These devices do not have a slot
		parameter. When addressing a processor in a ControlLogix
		or CompactLogix, the slot number corresponds to the slot in
		the rack containing the controller being addressed.
Func Code	332	Specifies the function code to be used in the command.
	333	332 - CIP Data Table Read
		333 - CIP Data Table Write
Data Type	Bool	Specifies the data type of the target controller tag name.
	SINT	
	INT	
	DINT	
	REAL	
	DWORD	
Tag Name		Specifies the controller tag in the target PLC.
Offset	0 to 9999	Specifies the offset database where the value corresponds to
		the Tag Name parameter.
Comment	<u> </u>	Optional 32-character comment for the command.

Class 3 Client/UClient [x] Commands Basic


Parameter	Value	Description
Enable	Enable	Specifies if the command should be executed and under
	Disable	what conditions.
	Conditional Write	ENABLE - The command is executed each scan of the
		command list
		DISABLE- The command is disabled and will not be executed
		CONDITIONAL WRITE - The command executes only if the internal
		data associated with the command changes
Internal Address	0 to 9999	Specifies the database address in the module's internal
		database to be associated with the command. If the
		command is a read function, the data received in the
		response message is placed at the specified location. If the
		command is a write function data used in the command is
		taken from the specified location.
Poll Interval	0 to 65535	Specifies the minimum interval to execute continuous
		commands. The parameter is entered in 1/10 of a second. If
		a value of 100 is entered for a command the command
		executes no more frequently than every 10 seconds.
Reg Count	1 to 125	Specifies the number of data points to be read from or written
		to the target device.
Swap Code	None	Specifies if the data from the server is to be ordered
	Word swap	differently than it was received. This parameter is typically
	Word and Byte	used when dealing with floating-point or other multi-register
	swap	values.
	Byte swap	None - No change is made (abcd)
		Word swap - The words are swapped (cdab)
		Word and Byte swap - The words and bytes are swapped (dcba)
		BYTE SWAP - The bytes are swapped (badc)
IP Address	XXX.XXX.XXX	Specifies the IP address of the target device to be addressed
		by this command
Slot	-1	The slot should always be -1.
Func Code	1	Specifies the function code to be used in the command.
	2	1 - Protected Write
	3	2 - Unprotected Read
	4	3 - Protected Bit Write
	5	4 - Unprotected Bit Write
-		5 - Unprotected Write
Word Address		Specifies the word address where to start the operation.
Comment		Optional 32-character comment for the command.

3.9 Configuring the EIP Processor Path

The EIP Processor Path parameter allows you to set or change the IP address of a device being addressed by a command. For example, a PLC. Settings here specify the information required to identify where alarms are to be sent.



1 To edit the EIP Processor path, expand the EIP Processor Path selection and click on PLX82-EIP-PNC > EIP PROCESSOR PATH > EIP PROCESSOR PATH.




Parameter	Description
Alarm IP Address	This is the IP address of the device being addressed by the command.
Alarm Slot	Use a value of -1 when interfacing to a SLC 5/05 or a PLC5. These devices do not have a slot parameter. When addressing a processor, the slot number corresponds to the slot in the rack containing the controller being addressed. In the platform, the controller can be placed in any slot and the rack may contain multiple processors. This parameter uniquely selects a controller in the rack.
Alarm TagName	A name assigned to the alarm.
Acyclic IP Address	The IP address of the device being addressed by the command.
Acyclic Slot	Use a value of -1 when interfacing to a SLC 5/05 or a PLC5. These devices do not have a slot parameter. When addressing a processor, the slot number corresponds to the slot in the rack containing the controller being addressed. In the platform, the controller can be placed in any slot and the rack may contain multiple processors. This parameter uniquely selects a controller in the rack.
Acyclic Tagname	A name assigned to the acyclic alarm.


2 Click OK.

4 Configuring the PROFINET Controller


Note: ProSoft fdt Configuration Software incorrectly allows for up to 36 PROFINET devices to be configured with an "Update rate" as low as 1ms. Since that configuration can produce over 70,000 frames per second, the PROFINET controller and devices will experience errors. ProSoft Technology is in the process of adding limitations to the configuration software, and until then, we have produced a guideline to aid in the proper configuration of the PROFINET controller. This guideline is available from the ProSoft website, accessible from the PLX82-EIP-PNC product page. The file is named "ProSoft-PROFINET-Net-Load-Calculator+v4.xlsx.




1 From the PCB window, double-click on the **PROFINET** icon.




2 This opens the ProSoft fdt Configuration Manager network view.



3 Double-click on the PLX82-EIP-PNC icon.



4 This opens the *Controller Network Settings* window.




- 5 Click on **Controller Network Settings** located in the *Navigation Area* pane of the *netDevice Configuration* window.
- 6 Set the name of the station for the controller, provide a description, and IP address.
- 7 When complete, click **OK**.

4.1 Importing GSD Files

PROFINET Device information files (typically GSD or GSDML) must be imported for all devices you intend to connect to through the PLX82-EIP-PNC. GSD and GSDML files are available from the PROFINET device manufacturer.


Important:

- For devices with GSDML XML Schema version 1.0, every module has one submodule assigned. No additional submodules can be added, and the assigned submodule cannot be removed.
- For devices with GSDML XML Schema version 2.0, you can configure the submodules, and these submodules can be added or removed from the corresponding module.
- The GSDML file differentiates between **fixed in slot**, **used in slot**, and **allowed in slot** modules. *Fixed in slot* and *Used in slot* modules are automatically configured. **Allowed in slot** modules can be configured.
- 1 Click on the **NETWORK** tab and then click on the **IMPORT DEVICE DESCRIPTION** icon.




2 Navigate to the location of your GSD or GSDML files and select the appropriate files for your devices.

3 Click **OPEN** and then click **YES**. The GSD file is displayed in the right pane.




4 Open the device folder to display the device icon(s).




4.2 Adding a Slave Device to the Project

1 Locate the slave from the Slave Catalog.



2 Drag and drop the slave onto the PROFINET bus line.




3 If you are installing multiple slave devices, perform the same steps to add them to the network.

4.3 Configuring a Slave Device


This procedure configures all PROFINET slave devices for the PNC. As slaves are configured, configuration information is automatically placed in the PLX82-EIP-PNC. This information is visible by double-clicking on the **PLX82-EIP-PNC** icon.

Note: The diagram only shows one slave device. All slaves on the network must be defined and configured according to the following steps:



- 1 Double-click on the slave device.
- 2 Click the ADD MODULE button.
- 3 Select an *Input* or *Output* space allocation.
- 4 Repeat the steps 2 and 3 above for additional Inputs or Outputs.

5 When complete, click APPLY and then click OK.




Parameter	Description
Slot	Displays the slot number assigned to the module. Clicking on the slot field
	displays a drop-down list of free slot numbers. Changing the slot number
	changes the sequence of the modules.
Sub Slot	Displays the sub slot assigned to a sub module. Clicking on the sub slot field
	displays a drop-down list of free sub slot numbers.
!	Slot icon tag. This indicates the usage of the submodule
	An icon in this field indicates that the Slot number, subslot number and
	module name are not changeable.
	No icon in this field indicates that the slot number, subslot number and
	module name are changeable.
Module	Module name as defined in the GSDML file.
Add Module button	Adds a module to the device configuration below the current line.
Add Submodule button	Add a submodule to the selected module of the device configuration below
	the current line.
Remove button	Removes the selected submodule from the configuration below the current
	line.
-	The arrow icon shows the current line in the table. This line is the reference
	for Add Module, Add Submodule, and Remove.

Note: Not all devices support sub-modules.

4.4 Verifying Slave Device Information


Slave devices are automatically configured. As configured, the new information is immediately visible in the module. To view device information, double-click on the **PLX82-EIP-PNC** module icon and then select the appropriate link.



4.4.1 Controller Network Settings

The Controller Network Settings display the following information:


- Name of Station
- Description of the station
- o IP Address, Network Mask, and Gateway Address



Parameter	Description	
Name of Station	Network name of the PROFINET controller. This must be a DNS	
	compatible name. 1 to 240 characters.	
Description	Symbolic name of the PROFINET controller DTM.	
IP Settings		
IP Address	IP address of the PROFINET controller.	
Network Mask	Network mask of the PROFINET controller.	
Gateway Address	Gateway address of the PROFINET controller.	

4.4.2 Device Table

The *Device Table* lists all devices connected and configured in the PROFINET Controller.




Parameter	Description
Activate	Use this checkbox to activate or deactivate a station
Index	This is editable. This allows you to set a user-defined sequence for the configured devices. However, when using acyclic messaging, the sequence always starts at 0. Therefore, the Device ID of the first slave in this list would be Index 0, followed by 1, 2, 3, etc.
Name of Station	Name of the device.
Device	Actual device name of the slave as specified in the GSD or GSDML file.
Description	Description of the device.
Vendor	Name of the vendor of the device.

You can activate and deactivate configured devices from this table. Simply click the checkbox to to clear the checkmark or click to place a checkmark which enables the device.

To change the Index number...

1 Click on the **INDEX** number to be changed.



- 2 Edit the Index number.
- 3 Click **OK** when done.


To change the name of the station...

- 1 Click on the *Name of Station* to be changed.
- 2 Edit the Name of Station.
- 3 When complete, click **OK**.

4.4.3 IP Address Table

The *IP Address Table* shows the IP address of each connected slave device. The IP address is assigned automatically based on incrementing the last octet based on the IP address of the PLX82-EIP-PNC. For example, if the controller IP address is 192.168.0.240, the first device added will have an IP address of 192.168.0.241.

Use this pane to view or change IP addresses. Changes to the *Network Mask* or *Gateway* address are not possible with the **INHERIT** checkbox checked. 'Checked' indicates that the *Network Mask* and *Gateway* address are taken from the controller.




Parameter	Description		
Name of Station	This is the name of the slave device.		
IP Address	This is the IP address of the slave device. The PNC transmits the IP address of		
	the slaves during startup.		
Inherit	Indicates whether the Network Mask and the Gateway Address are taken from		
	the controller.		
Network Mask	This is the network mask of the slave device. The PNC transmits the network		
	mask of the slave during startup to the slave, thereby configuring the device.		
Gateway Address	The is the gateway address of the slave device. The PNC transmits the		
	gateway address to the slave over the network, thereby configuring the device.		

To change the IP address...

- 1 Click on the IP address in the IP address column and enter the new address. The Network Mask and Gateway address columns are only editable with the INHERIT checkbox unchecked.
- 2 Click APPLY, then OK.

4.4.4 Process Data

The *Process Data* table serves as an external process data interface (for data transfer to a PLC unit). It lists the devices connected to the controller, and well as configured modules or input or output signals of the devices. This makes the fieldbus structure visible.




Parameter	Description
Туре	Device label provided by the hardware. Provides a description of the modules
	or input or output signals configured to the device.
Tag	Device name provided by the hardware (not changeable) or the symbolic name
	for the modules configured to the device or input/output signals (changeable).
SCADA	Indicates which module or single data is provided for the OPC server.

ProSoft Technology, Inc. Page 64 of 150

4.4.5 Address Table


The *Address Table* displays a list of all addresses used in the process data image. The displayed addresses refer to the PROFINET Controller (PNC). This page allows you to view current input and output data sizes per slave device.



Parameter	Description	
Auto addressing	Selected by default. If you want to set addresses manually, this checkbox	
	be unchecked (see Manual address updates).	
Display mode	Allows you to display the address data in decimal or hexadecimal format.	

CSV Export

This option allows you to export input and output addresses as a .CSV file (comma separated values).




- 1 Click the CSV Export button. The File Save dialog opens.
- 2 Navigate to a folder location, enter a filename, and then click SAVE.

The data file can be opened using a spreadsheet application or input into another application.

Manual Address Update

If manual addressing is allowed, input and output addresses of the PLX82-EIP-PNC may be assigned manually.

- 1 Uncheck the **AUTO ADDRESSING** checkbox.
- 2 Click on the address of a module.
- 3 Edit the field and type in a new address.
- 4 Click OK.



Parameter	Description		
Name of Station	Symbolic name of the assigned slave device.		
Module	Name of the module according to the GSD or GSDML file.		
Submodule	Displays submodule information.		
Туре	Specifies the input data type or output data type (IB, QB, IW, or QW)		
Length	Data length in bytes		
Address	Output or input data offset addresses.		

The configuration software reports an error if an address overlapping in the process data image was detected. If this occurs, correct the address for one of the two modules and enter an unused address.

ProSoft Technology, Inc. Page 67 of 150


4.4.6 FSU-/Port-Settings

The Fast Start Up (FSU) Port Settings pane is used to specify devices that must use a fast start up connection to establish the cyclic data exchange. Check with your device manufacturer to determine if your device must use FSU. All existing connections from the controller to the devices are displayed, including all ports at each device.

The MAU Type indicates whether the device should establish the connection automatically or whether fixed parameters are to be used.

Note: If you enable FSU to establish a fast connection for a port, use only the MAU type "100BASETXFD". If using the AUTO setting, the Auto negotiation and Auto crossover effects will prevent establishing a fast Ethernet connection.

1 Select Configuration > FSU-/Port-Settings in the navigation area.




2 Check the **FSU** box for PROFINET devices that must use a fast startup (FSU) connection to establish cyclic data exchange.

Parameter	Description	
Name	The symbolic name of the PROFINET slave device.	
Name of Station	This is the network name of the slave device. The name of the device is set in the	
	Device Table. The PNC uses the name of the station to identify the slave device	
	and to establish communication.	
	This name of the station here must match the name of the station set in the	
	PROFINET I/O device.	
MAU Type	The MAU type defines the physical settings (PHY) on the slave device. The MAU	
	must be set separately for each port on the device.	
	AUTO - Connections between devices are negotiated automatically. It may take 2-3	
	seconds for the physical connection to be established.	
	100BASETXFD - Connections between devices is fixed with 100 MBit/Full duplex.	
	IMPORTANT FOR HARDWARE WIRING:	
	Wire only between ports with the same port setting (MAU-type configuration).	
	Otherwise, a connection cannot be established between the devices.	
	Connect to ports that have different cross-over settings.	
FSU	Checking this box indicates that the device is configured for fast start up	
	connections to establish cyclic data exchange.	

4.4.7 Stations Timing

The Stations Timing pane allows you to edit station timings.


- 1 Navigate to Configuration > Stations Timing.
- 2 Name of Station This list contains all devices associated with the PNC. Select the station from the list.



- 3 Set the *Update time* in milliseconds.
- 4 Set the Watchdog time in milliseconds.
- 5 Click APPLY to save your settings.
- 6 When complete, click OK.

4.4.8 Controller Settings

The Controller Settings pane allows you to control the behavior of the PNC controller.



Parameter	Description				
Start of bus	Automatically by device or Controlled by application.				
communication	If Automatically by device, the PNC controller device starts with the data				
	exchange on the bus after initialization has ended.				
	If Controlled by application, the application program must activate data exchange				
	on the bus.				
	The default is typically set to Co	ntrolled by application.			
Application monitoring	Watchdog time is set per station in the Stations Timing window. This field				
	displays the watchdog time in milliseconds. The Watchdog time determines the				
	time in which the device watchdog must be re-triggered from the application				
	program while the application program monitoring is activated. When the watchdog time value is equal to 0, the watchdog is deactivated and				
	application program monitoring i	s also deactivated.			
	Watchdog time	Range of Value/Default Value			
	Permissible range of values	20 to 65535 ms			
	Default	1000 ms			
	Deactivated	0 ms			
Process image	Big Endian (Most Significant Byte first)				
storage format	Little Endian (Least Significant Byte first)				

ProSoft Technology, Inc. Page 70 of 150


Parameter	Description
Port Settings	Displays or selects Port 1 settings. This is used if Fast Start Up (FSU) is selected for PROFINET devices that use FSU connection to establish a cyclic data
	exchange.
	If FSU is check on a port, you must select 100BASETXFD . Otherwise, select
	AUTO.
IO State Information	Input Provider - Disabled, Bit, Byte
	Output Provider - Disabled, Bit, Byte
	Allows you to configure the PROFINET Input/Output Object Provider State
	(IOPS). This allows the PNC application program to detect whether data received from a slave is valid or not and vice versa.
	Disabled - The PROFINET controller application cannot detect whether the data received from the PROFINET slaves are valid or declare its output data sent to the slaves are valid or invalid.
	Bit - IOPS is handled as a bit list. Each sub-module description is represented by a single bit. If set to 1, the data is valid. If set to 0, the data is invalid. Sub-modules with input and output data simultaneously have IOPS in input and output directions.
	Byte - In the dual-port memory (DPM) of the PNC, IOPS is handled as a byte array. Each sub-module description is represented as a byte. If the byte is set to 0x80, the data is valid. Otherwise, the data is considered invalid. In this mode, the entire IOPS byte is directly copied from/to the cyclic frame, providing the PNC's application program the possibility of accessing all bits of IOPS. Typically, only the first bit of the IOPS byte states whether the data is valid or invalid.
Module Alignment	Byte boundaries
	2 Byte boundaries
	Module Alignment defines the addressing mode of the process data image. The
	addresses (offsets) of the process data are always interpreted as byte addresses.
	The Module Alignment then defines the addressing mode.

ProSoft Technology, Inc. Page 71 of 150


4.4.9 Ethernet Devices

The *Ethernet Devices* pane provides a view of all slave devices on the network after performing a search. It also allows you to edit each device. The device name must match the *Name of Station* field.


Select the ETHERNET DEVICES icon.



2 Click the **SEARCH DEVICES** button to start the search.



3 The current online devices appear in the grid.




Parameter	Description
MAC Address	Unique address of the device set by the device manufacturer.
Device Type	Name given to the device that provides a description of the device.
Device Name	Name of the device as a character string defined by the manufacturer.
IP Address	IP address of the device that can be set in the IP Address Table pane.
	The IP address must be unique and must fit into the current network. The IP
	address of 0.0.0.0 indicates that no IP address has been set.
Protocol	Supported protocol of the device.
Device ID	Identification number of the device. This is fixed by the manufacturer.
Vendor ID	Identification number of the device vendor assigned by PROFIBUS.
Device Role	Description of the function that the device has on the network. For example, device,
	controller, multi-device, etc.

ProSoft Technology, Inc. Page 74 of 150

Creating New, or Using Existing Configuration Information

The lower area of the *Ethernet Devices* pane allows you to change information returned by the search.




Note: If you are going to use a configuration from a different device, use the "Use Configuration of" section.

The current system allows you to change/set the device name and IP address. Highlight the device that you want to modify and click on the *Set Name*, *Set IP Address*, or *Other Functions* tabs to enter new information.


*Set Name (new configurations)

Enter the new device name and click the **SET NAME** button. If you are changing the name of the PROFINET controller, the name must match the name specified in the *Controller Network Settings* page.

For example, if the Device name in the Controller Network Settings pane is 'controller'...



Enter a name in the *New Device Name* parameter and click the **SET NAME** button:



*Set IP Address (new configurations)

Enter the IP address, Subnet mask, and Gateway address of this device and then click the **SET ADDRESS** button.

You can also obtain an IP address via DHCP by checking the *Get IP Address via DHCP* radio button.

*Other Functions - Signal or Reset the module to factory defaults.

- The **Signal** button causes the LED on the selected device to blink. This allows you to easily identify a specific device among other devices.
- The **Reset** to factory defaults button sets the device to back to factory defaults.

When complete, click **APPLY**, then **OK** to save changes.

Use Configuration of...

You can define whether the configuration for a device is created from scratch or use an existing configuration.

Creating a new configuration:

- 1 Uncheck the **USE CONFIGURATION OF** checkbox to create a new configuration, or check **USE CONFIGURATION OF** box if an existing configuration will be used.
- 2 Select the device whose configuration will be used for the selected device.



Setting a New Device Name

- 1 Uncheck the USE CONFIGURATION OF box.
- Click the SET NAME tab.

For PROFINET I/O devices (controller or device)...


- 1 The current name is displayed in the *Device name* field.
- 2 Enter a new device name in the New device name field.
 - If you are setting this device name as a temporary device name, check the temporary checkbox.
 - If you are setting this device name as a permanent change, make sure that the temporary checkbox is unchecked.
- 3 Click the **SET NAME** button. The new device name is now used as the current device name.

ProSoft Technology, Inc. Page 77 of 150

4.4.10 Viewing Configured Device Information

Device Info

The *Device Info* pane displays manufacturer information about the device, which is defined in the GSDML file.




Name	Value
Main family	Attribute of the GSDML family element. It contains the assignment of the device
	to a function class.
	One of the following values are allowed:
	General Drives
	Switching Devices
	• I/O
	• Valves
	Controllers
	• HMI
	• Encoders
	NC/RC
	Gateway
	Programmable Logic Controllers
	Ident systems
	PROFIBUS PA Profile
	Network Components Sensor
Product family	Attribute of the GSDML family element. It contains the vendor-specific
	assignment of the device to a product family. In addition to the main family, a
	device can be assigned to a vendor-specific product family.
DAP vendor name	Attribute of the GSDML ModuleInfo/VendorName element. The VendorName
	element contains the name of the device vendor.
	The device access point (DAP) is a module of the GSDML to describe the device
	parameters specific device. The device access point object contains most of the
	device-related keywords.
DAP hardware	Attribute of the GSDML ModuleInfo/HardwareRelease element. The
release	HardwareRelease element contains the hardware release of the DAP.

ProSoft Technology, Inc. Page 78 of 150

Name	Value	
DAP software	Attribute of the GSDML ModuleInfo/SoftwareRelease element. The	
release	SoftwareRelease element contains the software release of the DAP.	
Extended Address	Attribute of the GSDML DeviceAccessPointItem element. It depends on the	
Assignment	protocol for the assignment of the IP addresses supported by the DAP.	
	Default: "false" for Discovery and Configuration (DCP), "true" for Dynamic Host	
	Configuration Protocol (DHCP).	
Physical slots	Attribute of the GSDML DeviceAccessPointItem element. This list describes	
	which slots are supported by the DAP. The slot number of the DAP itself shall be	
	part of the list.	
Max. I/O data length	Attribute of the GSDML DeviceAccessPointItem IOConfigData element. It	
	contains the maximum length of the output and input data in octets.	
	MaxDataLength shall not be less than the highest value of MaxInputLength or	
	MaxOutputLength. It shall not be greater that the sum of MaxInputLength and	
	MaxOutputLength. If the keyword is not provided, the maximum length is the sum	
	of MaxInputLength and MaxOutputLength.	
Max input data length	Attribute of the GSDML DeviceAccessPointItem IOConfigData element. It	
	contains the maximum length of the data in octets which can be transferred from	
	the I/O device to the I/O controller. This length is defined by the sum of the output	
	data of all used submodules, the corresponding I/O producer status, and the I/O	
-	consumer status of the used input submodules.	
Max output data	Attribute of the GSDML DeviceAccessPointItem IOConfigData element. It	
length	contains the maximum length of the data in octets which can be transferred from	
	the I/O controller to the I/O device. This length is defined by the sum of the output	
	data of all used submodules, the corresponding I/O producer status, and the I/O	
-	consumer status of the used input submodules.	
Info text	GSDML ModuleInfo/InfoText element. This element contains human readable	
	additional text information about the device.	

Module Info

The **SELECT MODULE** drop-down list of the *Module Info* pane displays all available modules described in the GSDML file.




Name	Value	
Vendor ID	Vendor Identification Number	
Main family	Attribute of the GSDML family element. It contains the assignment of the device to a function class. One of the following values are allowed: General Drives Switching Devices I/O Valves Controllers HMI Encoders NC/RC Gateway Programmable Logic Controllers Ident Systems, PROFIBUS PA Profile	
Product family	 Network Components Sensors Attribute of the GSDML family element. It contains the vendor-specific assignment to a product family. In addition to the main family, a device can be assigned to a vendor- 	
	specific product family.	
Modules identifier	Identification number of the module.	
Order number	Contains the order number of the module. GSDML ModuleInfo/OrderNumber element.	
Hardware release	Contains the hardware release of the module. GSDML ModuleInfo/HardwareRelease element.	
Software release	Contains the software release of the module.GSDML ModuleInfo/SoftwareRelease element.	
Info text	Contains human-readable information about the module.GSDML ModuleInfo/InfoText element.	

ProSoft Technology, Inc. Page 80 of 150

5 PROFINET Start Input and Output Byte Offsets

The PNC option in PCB allows you to set the PROFINET Start Input Byte Offset and Start Output Byte Offset values within PLX82-EIP-PNC internal memory. You can also use this area to configure floating point or other multi-register values.

To edit these values, double-click on the PNC > PNC icon.



Parameter	Description
Start Input Byte Offset	Byte offset for input data
Start Output Byte Offset	Byte offset for output data
Swap Read Input Data Bytes	Use this parameter when dealing with floating-point or other multi-
	register values, as there is no standard method of storage of these data
	types in devices. This parameter can be set to order the register data
	received in an order useful by other applications.
	The following table defines the values and their associated operations:
	None. No change is made in the byte ordering.
	1 Words. The words are swapped.
	Words and Bytes. The words are swapped, then the bytes in
	each word are swapped.
	3 Bytes . The bytes in each word are swapped. The words should
	be swapped only when using an even number of words.
Swap Read Output Data Bytes	Use this parameter when dealing with floating-point or other multi-
	register values, as there is no standard method of storage of these data
	types in devices. This parameter can be set to order the register data
	received in an order useful by other applications. The following table
	defines the values and their associated operations:
	None. No change is made in the byte ordering.
	1 Words. The words are swapped.
	Words and Bytes. The words are swapped, then the bytes in
	each word are swapped.
	3 Bytes . The bytes in each word are swapped. The words should
	be swapped only when using an even number of words.

ProSoft Technology, Inc. Page 81 of 150

6 Acyclic Data

If you have a module that supports acyclic messaging and wish to use it, you must configure RSLogix 5000 to handle this. EIP requires a Class 3 function from the PLC.

Configure Message for Read

- 1 Click on MAIN ROUTINE from the Controller Organizer.
- 2 Expand the PLX82.ACYCLIC.READ.REQUEST controller tag.




Controller Tag	Description
PLX82.ACYCLIC.Read.	You can get the device ID from the Device table described under
Request.DeviceID	"Viewing the Device Table" in this manual. The Device ID is list in the
	Index column of the table. Remember that devices in the table start with
	the first device as 0, regardless of what number is displayed with the
	device. The second device in the table represents 1, the next device 2,
	and so on.
PLX82.ACYCLIC.Read.	Specify the slot number of the device. You can find this information in
Request.SlotNumber	the Address table described in the section entitled "Viewing and
	Modifying the Address Table" in this manual.
PLX82.ACYCLIC.Read.	Specify the sub-slot number of the device. You can find this information
Request.SubSlotNumber	in the Address table described in the section entitled "Viewing and
	Modifying the Address Table" in this manual.
PLX82.ACYCLIC.Read.	Enter the device index number. This should be available from the device
Request.Index	manufacturer documentation.
PLX82.ACYCLIC.Read.	Enter the number of bytes to read.
Request.Length	

ProSoft Technology, Inc. Page 82 of 150

Read Response


1 Scroll up to PLX82.CONTROL and expand it.



- 2 Enter the control bit in the PLX82.CONTROL.Acyclic.Read field and click ENTER.
- 3 The response is returned in the PLX82.ACYCLIC.Read.Response tags.

Configure Message for Write and Response

- 1 Expand the PLX82.ACYCLIC.WRITE.REQUEST controller tag.
- Write also contains the **PLX82.ACYCLIC.Write.Request.Length**. Specify the length of the data to be returned. The recommended limit is 495 bytes.



Controller Tag	Description
PLX82.ACYCLIC.Write.	You can get the device ID from the Device table described under "Viewing
Request.DeviceID	the Device Table" in this manual. The Device ID is list in the Index column
	of the table. Remember that devices in the table start with the first device
	as 0, regardless of what number is displayed with the device. The second
	device in the table represents 1, the next device 2, and so on.
PLX82.ACYCLIC.Write.	Specify the slot number of the device. You can find this information in the
Request.SlotNumber	Address table described in the section entitled "Viewing and Modifying the
	Address Table" in this manual.
PLX82.ACYCLIC.Write.	Specify the sub-slot number of the device. You can find this information in
Request.SubSlotNumber	the Address table described in the section entitled "Viewing and Modifying
	the Address Table" in this manual.
PLX82.ACYCLIC.Write.	Enter the device index number. This should be available fro the device
Request.Index	manufacturer documentation.
PLX82.ACYCLIC.Write.	495 bytes
Request.Length	

3 The Write Results are displayed in the PLX82.ACYCLIC.WRITE.RESPONSE tag.

Important Note: The PLX82.ACYCLIC.Read.Request.DeviceID, and PLX82.ACYCLIC.Write.Request.DeviceID, and can be found in the PNC Device Table through ProSoft fdt Configuration Manager. However, it is important to note that regardless of the index number listed in the Device Table, the first device in the list (for purposes of identification) is always 0. The Device Table indexes devices sequentially beginning at 1. Since the Device table Index is also editable, the first number listed


ProSoft Technology, Inc. Page 84 of 150

could be anything. For setting the DeviceID, the first device will be 0, followed by 1, 2, 3, etc.

7 CommonNet Data Map

This is an optional section that allows you to move already in the PLX82-EIP-PNC's internal database to another location in its database and is not required for normal operation. This feature is primarily used to transfer status data from our normally inaccessible upper memory (address 10000 and higher) down into the accessible lower memory (0 to 9999) so that it may be transferred to one or more connected devices.

1 From PCB, navigate to **COMMONNET > DATA MAP**.



- 2 To set data mapping to default levels, click the **SET TO DEFAULTS** button.
- 3 To configure the data map, click on the ADD Row button.

Parameter	Description
From Address	0 to highest Status Data address.
	Specifies the beginning internal database register address for the copy operation.
	The address can be any valid address in the user data area or the status data area
	in the gateway.
To Address	0 to 9999
	Specifies the beginning destination register address for the copy operation. This
	address must always be within the user data area. Make sure you specify a
	destination address that does not overwrite data that is stored in memory by one of
	the communication protocols running on the gateway.
Register Count	1 to 100
	Specifies the number of registers to copy.

		W 10 W 10 D 1 0 D 1 0		
Swap Code	•	Vord Swap, Word & Byte Swap, Byte Swap		
	•	You may need to swap the order of bytes in the registers during the copy process to change the alignment of bytes between different protocols. Use this parameter when		
	•	oating-point or other multi-register values since there is no standard of		
	storage of this	storage of this data type in slave devices. Swap Code Description		
	Swap Code	Description		
	No Swap	No change is made in the byte ordering (1234 = 1234)		
	Word Swap	The words are swapped (1234 = 3412)		
	Word and	The words are swapped, then the bytes in each word are swapped		
	Byte Swap	(1234 = 4321)		
	Bytes	The bytes in each word are swapped (1234 = 2143)		
Delay Preset	This paramete	er sets an interval for each Data Map copy operation. The value for the		
	Delay Preset	is not a fixed amount of time. It is the number of firmware scans that		
	must transpire	e between copy operations.		
	The firmware	The firmware scan cycle can take a variable amount of time, depending on the level		
	of activity of the	of activity of the protocol drivers running on the gateway and the level of activity on		
	the gateway's	communication ports. Each firmware scan can take from one to		
	several millise	econds to complete. Therefore, Data Map copy operations cannot be		
	expected to h	appen at regular intervals.		
	If multiple cop	by operations (several rows in the Data map section) happen too		
	frequently or	frequently or all happen in the same update interval, they could delay the process		
	scan of the ga	scan of the gateway protocols, which could result in slow data updates or missed		
	data on comn	data on communication ports. To avoid these potential problems, set the Delay		
	Preset to diffe	Preset to different values for each row in the Data Map section and set them to		
	higher, rather than lower, numbers.			
	For example,	For example, Delay Preset values below 1000 could cause a noticeable delay in		
	data updates	data updates through the communication ports. Do not set all Delay Presets to the		
	same value. Instead, use different values for each row in the Data Map such as			
	1000, 1001, a	and 1002 or any other different Delay Preset values you like. This		
	prevents the	copies from happening concurrently and prevents possible process		
	scan delays.			

The following parameters are located in the PLX82-EIP-PNC upper memory, starting at address 10000.

Parameter	Starting Address	Length (16-bit registers)
Module Status	10000	20
EIP Class 3 Servers	11000	80
EIP Class 3 Client1	12000	110
Status		
EIP Class 3 Client2	12400	110
Status		
EIP Class 3 UClient	12600	110
Status		
PNC Status	13000	594

8 Webpage

The PLX82-EIP-PNC webpage is accessible via web browser or through PCB via the built-in ProSoft Discovery Service. To access the PLX82-EIP-PNC webpage, enter the PLX82-EIP-PNC's IP address into your browser.



Status

Parameter	Description
Module Name	Name of the device as character string defined by the manufacturer
Ethernet Address (MAC)	The MAC address (MAC ID) is the unique (physical) Ethernet address of the
	device fixed by the manufacturer
IP Address	IP address of the of the PLX82-EIP-PNC that can be set via the ProSoft fdt
	Configuration Manager
Product Revision	Product revision of the PLX82-EIP-PNC firmware
Firmware Version Date	Firmware Version Date
Serial Number	Serial number of the PLX82-EIP-PNC
Status	Status of the module; Running, Communicating, Ready, or Error
Uptime	Counts the time from the last Reset/Power On

ProSoft Technology, Inc. Page 87 of 150

Functions

Parameter	Description	
Firmware Upgrade Click to upgrade the firmware in the PLX82-EIP-PNC. Or		
	instructed to do so by ProSoft Technology Technical Support.	
Set Date & Time	Click to set the date and time in the PLX82-EIP-PNC.	
Reboot Module	Click to reboot the PLX82-EIP-PNC.	
Technical Support	Click to be directed to ProSoft Technology Technical Support.	
Homepage	Click to go to the PLX82-EIP-PNC's homepage.	

Resources

Parameter	Description
ProSoft Technology	Click to be directed to the ProSoft Technology website.
PROFINET Technology	Click to be directed to the PROFINET website.

9 Diagnostics and Troubleshooting

There are three ways to troubleshoot the PLX82-EIP-PNC:

- Using the LEDs located on the front of the PLX82-EIP-PNC.
- Using the Diagnostics option within ProSoft Configuration Builder (PCB).

9.1 **LEDs**

All LEDs are found on the front of the module.



ProSoft Technology, Inc. Page 89 of 150


LED	State	Description
Pwr	OFF	Power is not connected to the power terminals or source is insufficient to
		properly power the gateway (200mA at 24 VDC is required)
	Solid GREEN	Power is connected to the power terminals. Verify that the other LEDs for
		operational and functional status come on briefly after power-up (check for
		burned-out LEDs).
Flt	OFF	Normal operation
	Solid RED	A critical error has occurred. Program executable has failed or has been
		user-terminated and is no longer running. Press Reset p/b or cycle power to
		clear error.
Cfg	OFF	Normal operation
	Solid AMBER	The unit is in configuration mode. Either a configuration error exists, or the
		configuration file is currently being downloaded or read. After power up, the
		configuration is read, and the unit implements the configuration values and
		initiates the hardware. This occurs during power cycle or after the Reset
Err	OFF	button is pressed. PROFINET is scanning configured slaves without error.
	Flashing Amber	
	Solid AMBER	, , , , , , , , , , , , , , , , , , ,
NS	Off	PROFINET controller is not configured or is incorrectly configured.
NO		No power or no IP address
	Solid Red Solid Green	Duplicate IP address Connected
	Flashing Red	Connection timeout
	Flashing Green	IP address obtained; no established connections
	Alternating Red	Self-test
MS	Off	No nouser
IVIO	Solid Red	No power
		Major fault
	Solid Green	Device operational
	Flashing Red	Minor fault
	Flashing Green	Standby
	Alternating Red	Self-test Self-test
	and Green	
Link/Act	OFF	No physical network connection is detected.
	Solid Green	Physical network connection detected. This LED must be ON solid for
		Ethernet communication to be possible.
100 Mbit	Off	No activity on the port.
(Port		
Speed)	Clashina Anaban	The Ethernesis and in activaly transposition or processing data
Link	Flashing Amber	The Ethernet port is actively transmitting or receiving data. A connection exists
Link	Green	The device sends/receives Ethernet frames.
Rx/Tx	Yellow (Floobing)	The device sends/receives Ethernet frames.
CVC	(Flashing)	
SYS	Green/Yellow	Operating system running
		Second stage boot loader is waiting for firmware.
	Yellow	Second stage boot loader missing. Contact Technical Support
C.C.	Off	Power supply for the device is missing, or hardware is defective
SF	Red (with BF Red)	No valid Controller License
	Red (flashing cyclic at 2 Hz)	System Error: Invalid configuration, watchdog error, or internal error
	Off	No error

ProSoft Technology, Inc. Page 90 of 150


LED	State	Description
BF	Red	No Connection: No Link
		or together with SF Red:
		No Controller License
	Red (Flashing	Configuration fault: not all configured I/O devices are connected.
	cyclic at 2 Hz	
	Off	No error

9.2 PCB Diagnostics


1 From PCB, right-click on the PLX82-EIP-PNC icon and select DIAGNOSTICS.




2 When the *Diagnostics* window opens, click the **SET UP CONNECTION** icon to browse for PLX82-EIP-PNC's IP address.



3 Enter the IP address of the PLX82-EIP-PNC. If you don't remember the IP address, click on the **Browse Device(s)** button to display all devices on the network.



- 4 Click **TEST CONNECTION** to ensure that a connection can be established.
- **5** Click **CONNECT** to obtain diagnostic results. Click on the parameters within the navigation tree on the left pane of the window.



9.2.1 PCB Diagnostics Menu Options

This view provides diagnostic and status information.

PLX82-EIP-PNC > Module > Version

Displays the module's current version information as well as additional information such as IP address, free memory, etc.

```
Time : 09.36.2
PLX82-EIP-PNC > MODULE > Version :
                                                        [Refresh Counter: 1]
                              :PLX82-EIP-PNC
PRODUCT NAME
                              :EPNC
:1.02.003
PRODUCT NAME CODE
SOFTWARE REVISION LEVEL
OPERATING SYSTEM REVISION
                              :2.6.30.10
RUN NUMBER
                              :#1
MY IP ADDRESS
                              :192.168.1.248
                              :00:0D:8D:A2:5E:95
MY ETHERNET ADDRESS (HEX)
PROGRAM SCAN COUNTER
                              :592096094
SYSTEM FREE MEMORY
                              :44666880
MODULE NAME
                              :PLX82-EIP-PNC
```

PLX82-EIP-PNC > Module > Data Map

Displays the PLX82-EIP-PNC data map.

```
PLX82-EIP-PNC > MODULE > Data Map : [Refresh Counter: 1]

DATA MAP LIST : FROM ADDR TO ADDR REG COUNT SWAP CODE

***** Scroll Up/Down *****
```

PLX82-EIP-PNC > PROFINET > Config

Displays the current PCB configuration settings.

```
PLX82-EIP-PNC > PROFINET > Config : [Refresh Counter: 1]

Start Input Byte Offset : 4000
Start Output Byte Offset : 0
Swap Read Input Data Bytes : No Swap
Swap Read Output Data Bytes : No Swap
Configuration Error : 0
```

PLX82-EIP-PNC > PROFINET > Module Information

Displays specific module information.

```
PLX82-EIP-PNC > PROFINET > Module Information : [Refresh Counter: 1]

Module Information : Module : PROFINET IO Controller
Version : 2.7.11 build 0
Device Number : 20002
Serial Number : 9043110
```

PLX82-EIP-PNC > PROFINET > Module Input Map

Displays the starting input data address and the size of the data (bytes) being passed.

PLX82-EIP-PNC > PROFINET > Module Output Map

Displays the starting output data address and the size of the data (bytes) being passed.

PLX82-EIP-PNC > PROFINET > Status

Displays the current PROFINET status.

PLX82-EIP-PNC > EIP Class 1 Connection > Config

Displays EIP Class 1 connections.

						Time : 09.56.35
PL)	X82-EIP-PNC > EIP Class 1	Conne	ection > C	onfig :	[Refresh Cou	ınter: 1]
EI	P Class 1 Connections	:Ir	nput Addr	Input Size	Output Addr	Output Size
Cor	nnection 1	:	2000	248	0	248
Cor	nnection 2	:	2250	248	250	248
Cor	nnection 3	:	2500	248	500	248
Cor	nnection 4	:	2750	248	750	248
Cor	nnection 5	:	3000	248	1000	248
Cor	nnection 6	•	3250	248	1250	248
Cor	nnection 7	•	3500	248	1500	248
	nnection 8		3750	248	1750	248

ProSoft Technology, Inc. Page 94 of 150

PLX82-EIP-PNC > EIP Class 1 Connection > Status

Displays Class 1 connection status.

```
PLX82-EIP-PNC > EIP Class 1 Connection > Status : [Refresh Counter: 1]

Configuration Error :0x0000
Number of EIP Class 1 (Implicit) Connections :0
```

PLX82-EIP-PNC > EIP Class 3 Server > Config

Displays Class 3 server parameters.

```
PLX82-EIP-PNC > EIP Class 3 Server > Config : [Refresh Counter: 1]

First File :10
File Size :1000
```

PLX82-EIP-PNC > EIP Class 3 Server > Comm Status

Displays comm status information of the EIP Class 3 server.

```
Time : 10.18.17
PLX82-EIP-PNC > EIP Class 3 Server > Comm Status :
                                                                 [Refresh Counter: 1]
 Server 0: Port : 0
  State
Estab
                                               :0
  Read
Write
                                               :0
 Server 1: Port : 0
State
Estab
                                  : 0.0.0.0
  Read
                                               :0
  Write
 Server 2: Port : 0
State
                                  : 0.0.0.0
  Estab
                                               :0
  Read
 Write
Server 3: Port : 0
                              IP : 0.0.0.0
  State
  Estab
                                               :0
  Read
 Write
Server 4: Port : 0
                                               :0
                                  : 0.0.0.0
  State
Estab
                                               · -1
                                               :0
  Write
```

PLX82-EIP-PNC > EIP Class 3 Client 0 > Config

Displays Class 3 Client 0 configuration.

```
PLX82-EIP-PNC > EIP Class 3 Client 0 > Config : [Refresh Counter: 1]

Commands :0
Min Dly :50
Resp TMO :1000
Retries :3
```

PLX82-EIP-PNC > EIP Class 3 Client 0 > Comm Status

Displays the communication status of the selected EIP Class 3 client.

```
PLX82-EIP-PNC > EIP Class 3 Client 0 > Comm Status :
                                                                          [Refresh Counter: 1]
Retries
Cur Cmd
                                        :ŏ
TNS
                                        :0
State
                                        :0
                                        :0
:0x0000
Timeout
Cfg Err
Cur Err
Last Err
                                        :0
Number of Command Requests
Number of Cmd Responses
Number of Command Errors
                                        :0
                                        0:0
                                        :ŏ
Number of Requests
Number of Responses
                                        :0
Number of Errors Received
                                        :0
Number of Errors Sent
```

PLX82-EIP-PNC > EIP Class 3 Client 0 > Commands

Displays the command list for the selected EIP Class 3 client.

```
Time: 10.48.48
PLX82-EIP-PNC > EIP Class 3 Client 0 > Commands :
                                                                 [Refresh Counter: 1]
COMMANDS 0 TO 9
                                          DBREG POLLINT COUNT SWAP NODE
                                                                                           SLOT
                                                         ILLEGAL FUNCTION
C1
C2
C3
                                       0
                                                       O ILLEGAL FUNCTION
                                                                                     0
                                                       0 ILLEGAL FUNCTION 0 ILLEGAL FUNCTION
                                              0
                                       ŏ
                                                                                     ŏ
C4
C5
C6
C7
                                                         ILLEGAL FUNCTION
                                                         ILLEGAL FUNCTION ILLEGAL FUNCTION
                                       0
                                                                                     0
                                                          ILLEGAL FUNCTION
C8
                                       0
                                                          ILLEGAL FUNCTION
                                                       0 ILLEGAL FUNCTION
                                                        ****
                                     Scroll Up/Down
```

PLX82-EIP-PNC > EIP Class 3 Client 0 > Cmd Errors (Decimal)

Lists command errors in decimal format.

PLX82-EIP-PNC > EIP Class 3 Client 0 > Cmd Errors (Hex)

Lists command errors in hexadecimal format.

```
Time : 10.57.50
PLX82-EIP-PNC > EIP Class 3 Client 0 > Cmd Errors(Hex) : [Refresh Counter: 1]
H0
H10
                                  0000
                                        0000
                                              0000
                                                     0000
                                                           0000
                                                                 0000
                                                                       0000
                                                                             0000
                                  0000
                                        0000
                                              0000
                                                    0000
                                                           0000
                                                                 0000
                                                                       0000
                                                                             0000
                          ***** Scroll Up/Down ****
```

ProSoft Technology, Inc. Page 96 of 150

PLX82-EIP-PNC > EIP Processor Path > Config

Displays the EIP Processor Path configuration.

```
PLX82-EIP-PNC > EIP Processor Path > Config : [Refresh Counter: 1]

Alarm IP Address : 192.168.0.59
Alarm Slot : -1
Alarm Tagname : Alarm

Acyclic IP Address : 192.168.0.59
Acyclic Slot : -1
Acyclic Tagname : Acyclic
```

PLX82-EIP-PNC > EIP Processor Path > Status

Displays the EIP Processor Path status.

```
PLX82-EIP-PNC > EIP Processor Path > Status : [Refresh Counter: 1]

PNC Respond Count :0
PNC Alarm Respond Count :0
PNC Acyclic Command Count :0
Retries :0
TNS :0
State :0
Timeout :0
Current Error :0
Last Error :0
Number of Command Requests :0
Number of Command Errors :0
Number of Command Errors :0
Number of Command Errors :0
Number of Errors Received :0
Number of Errors Sent :0
```

Parameter	Description
PNC Respond Count	Represents the total number of PROFINET responses saved in the queue.
PNC Alarm Respond Count	Represents the total number of PROFINET Alarm Responses saved in the
	queue.
PNC Acyclic Command	Represents the total number of PROFINET acyclic commands saved in the
Count	queue.
Retries	Number of messages sent but exceeded the 100ms timeout and had to be
	retried
TNS	Transaction Number. Increments each time a transaction such as an alarm
	or acyclic response occurs.
State	Displays the current command state:
	0: Client Initialization
	1: Session Creation
	2: Wait for Session
	3 Open for Session
	4: Command Ready
	5: Command Delay
	6: Send Command
	7: Wait for Command Response
	8: Prepare Next Command
	9: Verify Command
	10: Close Connection
	11: Close Session
Timeout	100ms. Amount of time before trying to reconnect to the socket to retry the
	send.
Current Error	Current error code number detected by the module.

ProSoft Technology, Inc. Page 97 of 150

Parameter	Description
Last Error	Previous error code detected by the module.
Number of Command Requests	This value is increased each time a Command Request is issued by the client.
Number of Cmd Responses	This value is increased each time a Command Response is received by the client.
Number of Command Errors	This value is increased each time an error message is received from a remote device or a local error is generated for a command.
Number of Errors Received	Represents the number of errors received from the PNC.
Number of Errors Sent	Represents the number of errors sent from the PNC.

9.2.2 PROFINET General Status Codes

Status Code	Description
0x00000000L	Operation successful
0xC000001L	Common error, detailed error information optionally present in the data area of
	the packet
0xC0000002L	Unexpected failure
0xC0000003L	Out of memory
0xC0000004L	Unknown command in packet received
0xC0000005L	Unknown destination in packet received
0xC0000006L	Unknown destination ID in packet received
0xC0000007L	Packet length is invalid
0xC0000008L	Invalid extension in packet received
0xC0000009L	Invalid parameter in packet found
0xC000000CL	Watchdog error occurred
0xC000000DL	List type is invalid
0xC000000EL	Handle is unknown
0xC000000FL	A packet index is not in the expected sequence
0xC0000010L	The amount of fragmented data contained in the packet sequence is too large
0xC0000011L	The packet done function has failed
0xC0000012L	A packet failed to send
0xC0000013L	Packet request from packet pool has failed
0xC0000014L	Release of a packet from the packet pool has failed
0xC0000015L	The get packet pool load function has failed.
0xC0000016L	The get queue load function failed
0xC0000017L	The waiting for a packet from queue failed
0xC0000018L	The posting of a packet has failed
0xC0000019L	The peek of a packet from queue has failed
0xC000001AL	Request already running
0xC000001BL	Creating a timer failed
0xC0000100L	General initialization fault
0xC0000101L	Database access failure
0xC0000102L	Controller parameter cannot activate at state operate
0xC0000103L	Slave parameter cannot activate at state operate
0xC0000200L	Watchdog time is out of range
0xC0000201L	Application is already registered
0xC0000202L	No application registered
0x0000F005L	Fragment accepted
0xC000F006L	Reset required

9.2.3 PROFINET Device Errors

Error Code	Description
D13 to D31	Unused, set to zero
D12	Inactive module present
D11	Module DiffBlock present
D10	Packet too small
D9	Diagnosis buffer overwritten
D8	Diagnosis buffer overflow
D7	Diagnosis - disappeared
D6	Diagnosis data present for I/O device
D5	IO - Device deactivated
D4	IO - Device parameter fault
D3	IO - Device invalid response
D2	IO - Device configuration fault
D1	IO - Device not ready
D0	IO - Device does not exist

9.2.4 Acyclic Read/Write Communication Status

Status Code	Description
0x00000000	Status OK
0xC00A0012	Insufficient memory for this request
0xC00A0014	This request cannot be served in current CMCTL state
0xC00A0018	Error while sending a packet to another task
0xC00A0040	The CMCTL protocol-machine restored from index invalid
0xC00A0041	The index of CMCTL protocol machine is invalid
0xC00C0030	Too many outstanding RPC-requests for this I/O device
0xC00C0031	Error while sending internal messages to another task
0xC00C0032	The handle used for I/O device is wrong
0xC00C0051	The current bus state is OFF and no frames can be sent
0xC02E0100	Generic RPC error code. See Acyclic Read/Write PNIO Remote Procedure Call
	Status code for details.
0xC02E0200	Error while sending internal messages to another task
0xC02E0201	Creating a TLR-Timer-packet in RPC task failed due to insufficient memory
0xC02E0605	The handle to RPC-client instance is invalid
0xC02E0606	The maximum number of outstanding RPC-Requests for this RPC-Clients
	instance is reached
0xC02E0607	RPC-client instances can only connect to an IO-Device if there are no outstanding
	RPC Requests. There is currently at least one RPC-Request outstanding
0xC02B0024	The message ID of the request is incorrect; out of sequence

ProSoft Technology, Inc. Page 100 of 150

9.2.5 Acyclic Read/Write PNIO Remote Procedure Call Status

Status Code	Description
0x00000000	Status OK
0xC02E0010	Initiating CLRPC - Client failed
0xC02E0011	Initiating CLRPC - Server failed
0xC02E0012	Initiating CLRPC - Endpoint Mapper failed
0xC02E0013	Creating message queue failed
0xC02E0014	Identifying Irv_EDD failed
0xC02E0015	Getting the MAC address failed
0xC02E0100	Generic RPC-error code. See Acyclic Read/Write Communication Status for details
0xC02E0101	There was not enough memory allocated to receive the entire I/O device's
	Connect Response PDU. Most likely, it contains a very large ModuleDiff-Block
0xC02E0102	The fatal error callback function is already registered
0xC02E0200	Error while sending an internal message to another task
0xC02E0201	Creating a TLR-Timer-packet in RPC task failed due to insufficient memory
0xC02E0202	The reference counter value is invalid
0xC02E0203	The port handle is invalid
0xC02E0204	The soft timer is already active
0xC02E0300	The parameter "uiMaxReg" (maximum amount of RPC mapper registrations) is invalid
0xC02E0301	The requested endpoint mapper index is invalid
0xC02E0303	The state of endpoint mapper is invalid for this request
0xC02E0304	The endpoint mapper is waiting for close confirmation and therefore its status is
	invalid for this request
0xC02E0305	The status of endpoint mapper is unknown
0xC02E0306	The status of endpoint mapper is not "Ready"
0xC02E0307	Invalid parameter
0xC02E0308	CLRPC_EPMap_Deregister_req() is not allowed because at least one RPC server is registered to this endpoint mapper
0xC02E0400	An error occurred during server initialization
0xC02E0401	The maximum number of registered RPC-Servers is exceeded, or the maximum number of outstanding requests is exceeded
0xC02E0402	Creating TLR timer for RPC server failed
0xC02E0403	There is no RPC server registered that could be de-registered
0xC02E0405	The handle to endpoint mapper is invalid
0xC02E0406	The status of endpoint mapper is invalid
0xC02E0407	The handle to RPC server instance is invalid
0xC02E0408	There is at least one object register for the RPC server instance;
	CLRPC_ServerDeregister_req() cannot proceed
0xC02E0409	Invalid parameter "ulMaxRecv" in request packet
0xC02E040A	Invalid parameter "ulMaxSend" is request packet
0xC02E040B	Invalid RPC server element "ptElem". Internal RPC error
	The RPC request was canceled
0xC02E040C	•
	The state of RPC server is invalid for this request
0xC02E040D	'
0xC02E040C 0xC02E040D 0xC02E040E 0xC02E040F	The activity has already been initialized
0xC02E040D 0xC02E040E 0xC02E040F	The activity has already been initialized The RPC server received in invalid (unexpected) response packet
0xC02E040D 0xC02E040E 0xC02E040F 0xC02E0501	The activity has already been initialized The RPC server received in invalid (unexpected) response packet The handle to the RPC server instance is invalid
0xC02E040D	The activity has already been initialized The RPC server received in invalid (unexpected) response packet

ProSoft Technology, Inc. Page 101 of 150


Ctatus Cada	Description
Status Code	Description
0xC02E0601	The maximum number of parallel RPC client instances has been reached
0xC02E0602	Creating TLR timer for RPC client instance failed
0xC02E0604	The state of endpoint mapper is invalid for this request
0xC02E0605	The handle to the RPC client instance is invalid
0xC02E0606	The maximum number of outstanding RPC requests for this RPC client instance has been reached
0xC02e0607	RPC client instances can only connect to an I/O device if there are no outstanding RPC requests. Currently, at least one RPC request is outstanding
0xC02E0608	The RPC client instance you tried to use is going to deregister right now. Aborting your request!
0xC02E0609	Invalid RPC client instance element "ptElem". Internal RPC error
0xC02E060A	The LONG timeout TLR timer for an outstanding RPC request hit. Used internally by RPC only
0xC02E060B	Invalid sequence number in RPC message receive by RPC client instance
0xC02E060C	Canceling a running request timeout out. This RPC client is no longer usable
0xC02E060D	The RPC client did not have a packet to return
0xC02E060E	The RPC client received a request with an unexpected flag value.
0xC02E060F	The request was aborted because the RPC client was unbound
0xC02E0610	The maximum resend number was reached by the activity.

ProSoft Technology, Inc. Page 102 of 150


9.3 Network Diagnostics

There may be instances where you want to look at diagnostic information on a particular network device.


1 From PCB, click on the **PROFINET** icon.




2 This launches the ProSoft fdt Configuration Manager application.



3 In the Solution Explorer pane, double-click on **NETX DRIVER**.



4 A *netX Driver* tab appears to the right of the *Network* tab. Click the **NETX DRIVER** tab to open the *TCP Connection* page.



- The netX Driver is used to connect *ProSoft fdt Configuration Manager* configuration software to the device via a TCP/IP connection.
- 6 Ensure that the *Enable TCP Connector* parameter is selected. With the *Enable TCP Connector* box checked, the netX Driver can communicate with other devices via the TCP/IP interface. If *Enable TCP Connector* is not set (checked), the ODM server must be started in order for the new settings to be valid.
- 7 Enter the IP address of the EIP port of the PLX82-EIP-PNC.
- 8 Click SAVE.


OR...

- 1 Check the USE IP RANGE checkbox.
- 2 Enter a starting IP address and an ending IP address range.
- 3 Click the SAVE icon.


Parameter	Description
Enable TCP Connector	Checked: Communication between the software and the device via TCP/IP
(Restart of ODM required)	can occur.
	Unchecked: Communication between the software and the device via
	TCP/IP cannot occur.
	Note: If the checkmark for this setting is set or removed, the ODM server
	must be restarted.
Select IP Range	This allows existing IP ranges to be selected. Use the "+" symbol to add an
	additional IP range or the "x" symbol to remove an IP range.
Scan Timeout	Specifies how long to wait for a response that indicates session
	establishment.
	10 to 10,000 ms. The default is 100 ms.
Disable IP Range	Checked: No connection
	Unchecked: the netX Driver tries to establish a connection using the
	configured TCP/IP interface.
IP Address (Left)	Enter the IP address of the device (when "Use IP Range" is not checked)
	Enter the start address of the IP scanning range if "Use IP Range" is
	checked.
Use IP Range	Checked: An IP address range is used.
IP Address (Right)	Enter the ending address of the IP scanning range (if "Use IP Range" is
	checked)
Address Count	Displays the scanning range address count, depending on the selected IP-
	start or IP-end address.
TCP Port	Identifies the endpoint of a logical connection or addresses a specific
	endpoint on the device or PC.
Send Timeout	Maximum time before the transfer of the transmission data is canceled
	when the send process fails. For example, the transfer buffer is full.
	100 to 60,000 ms
	Default (TCP/IP) is 2000 ms.
Reset Timeout	Maximum time for a device reset, including the re-initialization of the
	physical interface used for communication.
	100 to 60,000 ms
	Default (TCP/IP) is 2000 ms
Keep Alive Timeout	The Keep-Alive mechanism is used to monitor whether the connection to
	the device is active. Connection errors are detected using a periodic
	heartbeat mechanism. This mechanism is initiated after the set time has
	elapsed if communication has failed.
Restore	Resets all settings in the configuration dialog to the default values.
Save	Save all settings made in the configuration dialog for the selected
	connection type.
Save All	Save all settings made in the configuration dialog for all connection types.

ProSoft Technology, Inc. Page 105 of 150

1 From the Solution Explorer dialog box, double-click **DEVICE ASSIGNMENT**.




2 Click on the **DEVICE ASSIGNMENT** tab and then click **SCAN**. The system scans for all devices that can be connected to the ProSoft fdt Configuration Manager software.



Parameter	Description
Device Selection	Select "suitable only" or "all" devices
Device	Device class of the PROFINET devices
Hardware Port 0/1/2/3	Indicates what hardware is assigned to a communication interface
Slot Number	Not applicable
Serial Number	Serial number of the device
Driver	Name of the driver
Channel Protocol	Displays the firmware loaded to a channel.
Access Path	Access path to different data to devices. Displays the IP address and port of
	the device. Also displays channel number 0 to 3.

3 Select the appropriate device by clicking the checkbox.




4 Click the SAVE icon.


9.3.1 Establishing a Diagnostic Connection

Once you have configured the *netx Driver* and *Device Assignments*, you can create a TCP connection between your PC and the PLX82-EIP-PNC.

1 From the ProSoft fdt Configuration Manager page, click the **NETWORK** tab.




2 Right-click on the PLX82-EIP-PNC icon, and select CONNECT. You can also click on the CONNECT icon at the top of the page.




Page 109 of 150


3 The module information located above the icon is highlighted in green once the connection is established.



4 Right-click on the PLX82-EIP-PNC icon and select DIAGNOSIS.



5 The Diagnostic pane opens with General Diagnosis information displayed.



9.3.2 General Diagnosis

The *General Diagnosis* pane provides information on the device state as well as other general diagnostic parameters.

LED	Description	Color
Device State		
Communication	Indicates whether the PROFINET device executes	Green - In communication state
	during network communication.	Gray - Not in communication state
Run	Indicates whether the PROFINET device has been	Green - Configuration OK
	configured correctly	Gray - Incorrect configuration
Ready	Indicates whether the PROFINET device has been	Yellow - Device is Ready
	started correctly. The PROFINET device waits for a	Gray - Device is not ready
_	configuration.	
Error	Indicates whether the PROFINET device recorded a	Red - Error
	device status error (see Extended Diagnosis)	Gray - No Error
Network State	I I' (I II II DDOENET I : : : I (•
Operate	Indicates whether the PROFINET device is in data	Green - In Operation state
	exchange. In a cyclic data exchange, the input or output data is transmitted to the PROFINET device.	Gray - Not in Operation state
ldle	Indicates whether the PROFINET is in Idle state	Yellow - In Idle state
iule	indicates whether the FROI INCT is in the state	Gray - Not in Idle state
Stop	Indicates whether the PROFINET device is in Stop	Red - In Stop State
оюр	state. There is no cyclic data exchange on the	Gray - Not in Stopped state
	PROFINET network. The PROFINET device was	Cruy Mot in Gtopped Gtate
	stopped by the application program, or it changed	
	the Stop state because of a bus error.	
Offline	The PROFINET device configuration is offline if it	Yellow - In Offline state
	does not have a valid configuration.	Gray - Not in Offline state
Configuration		
State		
Configuration	Indicates whether the PROFINET device	Yellow - Configuration locked
locked	configuration is locked to avoid configuration data	Gray - Configuration not locked
	writeover.	
New Configuration	Indicates whether a new PROFINET device	Yellow - New configuration pending
pending	configuration is available.	Gray - No new configuration pending
Reset Required	Indicates whether a firmware reset is required as a new PROFINET device has been loaded into the	Yellow - Reset required
	device	Gray - No reset required
Bus On	Indicates whether the bus communication was	Green - Bus On
	started or stopped (i.e., whether the device is active	Gray - Bus Off
	on the bus or not bus communication to the device	
	is possible and no response messages are sent	

Communication Error - Displays the name of the communication error. If the cause of the error is resolved, the value is set to zero again.

Watchdog Time - Displays the watchdog time in ms.

Error Count - This field holds the total number of errors detected since power-up. The protocol stack contains all sorts of errors in this field, regardless of whether they were network related or caused internally.

9.3.3 Master Diagnosis

The *Master Diagnosis* dialog provides the slave state, slave errors, and slaves configured active or in diagnostic mode.




Parameter	Description
Slave state	Indicates whether the current slave state is OK.
	The slave state field indicates whether the Master is in cyclic data
	exchange to all configured slaves. If there is at least one slave missing,
	or if the slave has a diagnostic request pending, the status is set to
	Failed. For protocols that support non-cyclic communication only, the
	slave state is set to OK as soon as a valid configuration is found.
	Values: Undefined, OK, Failed
Slave error log indicator	Indicates whether the Slave Error Log indicator is available.
	The Error Log Indicator field holds the number of entries in the internal
	error log. If all entries are read from the log, the field is set to zero.
	Values: Empty, Available
Configured slaves	Displays the number of configured slaves.
	Number of configured slaves on the network according to the slave list
	derived from the configuration database created by the configuration
	software. This list includes the slaves to which the master must open a
	connection.
Active Slaves	Displays the number of active slaves.
	Number of slaves in data exchange mode. The list includes the slaves to
	which the master has successfully opened a connection.
Slaves with diagnostic	Displays the number of slaves with diagnostic.
	The number of slaves with diagnostic or errors.

ProSoft Technology, Inc. Page 112 of 150

9.3.4 Station Diagnosis

The Station Diagnosis dialog displays the current status of all slaves.




Parameter	Description
Status	Green - Running
	Yellow - Diagnosis state
	Blue - Not found
	Red - Error
Name of Station	Name of slave device
IP Address	IP Address of slave device

ProSoft Technology, Inc. Page 113 of 150

9.3.5 Firmware Diagnosis

The Firmware Diagnosis dialog displays task diagnosis information of the firmware.



Firmware: Name of the most current firmware.

Version: This number represents the stack version, not the firmware version of the module. The firmware version of the module is shown on the module web service.

Date: Displays the date of the PROFINET stack version.

Parameter	Description
Task	Displays the task number.
Name of task	Displays the name of the actual task.
Version	Version of the task.
Priority	Displays the priority of the task.
Description	Displays the description of the task.
Status	Status of the task.

ProSoft Technology, Inc. Page 114 of 150


9.3.6 Extended Diagnosis

The *Extended Diagnosis* dialog contains a list of diagnosis structures such as online counter, states, and parameters. Access requires an online connection between the ProSoft fdt Configuration Manager and the PROFINET Controller.

Folder	Contains
RX_SYSTEM	Task Information
DPM_COM0_SMBX	Task Information
DPM_COM0_RMBX	Task Information
TirTimer	Task Information
MARSHALLER	Task Information
T_PNIO_EDD	Task Information
	General Diagnosis Info
	Extended Diagnosis Info
	XMAC Diagnosis Structure
T_PNIO_ACP	Task Information
	General Diagnosis Info
	Extended Diagnosis Info
T_PNIO_DCP	Task Information
	General Diagnosis Info
	Extended Diagnosis Info
T_PNIO_MGT	Task Information
	General Diagnosis Info
	Extended Diagnosis Info
TCP_UDP	Task Information
	IP Information
	IP Packet Count
	TCP_UDP Information
T_RPC	Task Information
	General Diagnosis Info
	Extended Diagnosis Info
T_PNIO_CMCTL	Task Information
	General Diagnostics
	Extended Diagnostics
	NRPM (Device NameResolution) results
T DNIO ADOTI	Connection Establishment results
T_PNIO_APCTL	Task Information
	General Diagnosis Info
T DNIO ADCEC	Extended Diagnosis Info Task Information
T_PNIO_APCFG	
	General Diagnosis Info Extended Diagnosis Info
SNMP Server	Task Information
Mib Database	Task Information
LLDP-Task	Task Information
Packet Router	Task Information
racket Router	1 dSN IIIIOIIIIdiiOII

ProSoft Technology, Inc. Page 115 of 150

RX SYSTEM > Task Information



Parameter	Description
Identifier	Identification number of the task.
Major version	Task version, contains all incompatible changes.
Minor version	Task version, contains compatible changes.
Maximum packet size	Maximum packet size that the task sends.
Default queue	Queue handle accessible via DPM by mailbox
Unique Identifier	16-byte indicator used for task identification and its affiliation (e.g.,
	to a stack)
Init result	Error Code, 0 = no error
	The description of error codes is available in the following sections.

General Diagnosis Information

	General Diagnosis Information
ask states	
Name	Value
Last TLR error code	Operation succeeded.
Last PNIO error code	0x00000000
TLR Error Counter (may count single error seve	0
PNIO Error Counter (may count singe error sev	0
Active PM Counter	0
Send Packet Error Counter	0
Malloc Error Counter	0
ErrExternal (Received unsupported Requests)	0
ErrInternal (Received unsupported Confirmations)	0
Maximum Pool usage	0
Current Pool usage	0

Parameter	Description
Last TLR error code	Error code of the last internal error.
Last PNIO error code	Error code of the last externally occurred error which has been reported
	by an I/O device.
TLR Error Counter	Counts the number of occurred TLR error codes.
PNIO Error Counter	Counts the number of occurred PNIO error codes.
Active PM Counter	Counter of the active protocol machines in the task.
Send Packet Error Counter	Counts how often a task sends a packet to another task and this fails.
Malloc Error Counter	Counts how often storage capacity is requested in the operating system
	and the operating cannot follow this demand.
ErrExternal	Counts how often an unknown request packet was received.
ErrInternal	Counts how often an unknown confirmation packet was received.
Maximum Pool Usage	Counts how many pool elements were used simultaneously
	(maximum).
Current pool usage	Counts the number of pool elements currently in use.

ProSoft Technology, Inc. Page 117 of 150

T PNIO EDD Extended Diagnosis Information

	Extended Diagnosis Information
ask states	
Name	Value
Cyclic Frames sent	0
Missing cyclic Frames counter (CPM)	0

Parameter	Description
Cyclic Frames sent	Counts cyclical frames that were sent.
Missing Cyclic Frames counter (CPM)	Counts the missing cyclical frames agreed on.

XMAC Diagnosis Structure

ask states	
Name	Value
FramesTransmittedOk	0
SingleCollisionFrames	0
MultipleCollisionFrames	0
LateCollisions	0
LinkDownDuringTransmission	0
UtxUnderflowDuringTransmission	0
FramesReceivedOk	0
FrameCheckSequenceErrors	0
AlignmentErrors	0
FrameTooLongErrors	0
RuntFramesReceived	0
CollisionFragmentsReceived	0
FramesDroppedDueLowResource	0
FramesDroppedDueUrxOverflow	0

The values of the XMAC diagnosis structure are read every 2 seconds from the XMACs (hardware).

Parameter	Description	Value/Range of Values
FramesTransmittedOK	Number of the correctly received Ethernet frames.	0 to 4,294,967,295
SingleCollisionFrames	Number of the frames involved in a collision.	0 to 4,294,967,295
MultipleCollisionFrames	Number of frames involved in several collisions.	0 to 4,294,967,295
LateCollisions	Number of clashed frames after at least 512 bits of the frame have been transmitted.	0 to 4,294,967,295
LinkDownDuringTransmisstion	Number of frames sent during a broken connection.	0 to 4,294,967,295
UtxUnderflowDuringTransmissi on	Number of frames sent erroneously because of buffer underflow.	0 to 4,294,967,295
FramesReceivedOK	Number of correctly received frames.	0 to 4,294,967,295
FrameCheckSequenceErrors	Number of corruptly received frames. (FCS check failed)	0 to 4,294,967,295
AlignmentErrors	Number of frames received in which its length is not an even number of bytes.	0 to 4,294,967,295

Parameter	Description	Value/Range of Values
FrameTooLongErrors	Number of frames received in which its length exceeds the maximum permitted frame length.	0 to 4,294,967,295
RuntFramesReceived	Number of frames received undamaged with a length of 42 to 63 bytes. (Under run of the minimum permitted frame length)	0 to 4,294,967,295
CollisionFragmentsReceived	Number of frames received corruptly with a length of 42 to 63 bytes. (FCS check failed)	0 to 4,294,967,295
FramesDroppedDueLowResour ce	Number of frames lost because of a memory deficiency.	0 to 4,294,967,295
FramesDroppedDueUrxOverflo w	Number of frames lost because of buffer underflow.	0 to 4,294,967,295

T PNIO ACP Extended Diagnosis Information

	Extended Diagnosis Information
ask states	
Name	Value
Received unsupported Frames	0
Active Consumer Protocol Machines	0
Active Provider State Machines	0
Received high priority alarms	0
Received low priority alarms	0

Parameter	Description
Received unsupported	Frames which cannot be used by the consumer.
frames	
Active Consumer Protocol	Number of state machines supervised by the cyclical communication
Machines	consumer = receiver (supervises frames of the I/O devices received)
Active Provider State	Number of state machines, the frames transmit to the devices
Machines	
Received high priority	Number of high priority alarms for PROFINET IO
alarms	
Received low priority alarms	Number of low priority alarms for PROFINET IO

PNIO DCP Extending Diagnosis Information

Name	Value
Active Application Timers Counter	0
Erroneous Frames received	0
Ident Request sent Counter	0
Ident Response received Counter	0
DCP Set Requests sentcounter	0
Positiv DCP Set Responses	0
Negativ DCP Set Responses	0
DCP Hello Requests Received	0
Hello reported to NRPM	0

The PNIO_DCP Extended Diagnosis information displays the counter reading of the four state machines from the PROFINET I/O DCP protocol.

- MCR Multicast Receiver
- UCR Unicast Receiver
- MCS Multicast Sender
- UCS Unicast Sender

Parameter	Description
Active Application Timers Counter	Software timer running in the task.
Erroneous Frames received	Counter for erroneous frames received.
Ident Request sent Counter	Counter for Ident Request send Counter.
Ident Response received Counter	Counter for Ident Responses received.
DCP Set Requests sentcounter	Counter for DCP Set Request sent.
Positive DCP Set Responses	Counter for Positive DCP Set Responses.
Negative DCP Set Responses	Counter for Negative DCP Set Responses.
DCP Hello Requests Received	Counter for DCP Hello Requests received.
Hello reported to NRPM	Counter for Hello reported to the NRPM state machine.

ProSoft Technology, Inc. Page 120 of 150

T PNIO MGT Extended Diagnosis Information

Name	Value
Ident Requests Sent	0
Ident Responses received (Conflict)	0
Ident Responses received (Forbid)	0
Ident Responses received (Permit)	0
Identify Q Indications received (Multiple)	0
Identify Q Indications received (Forbid)	0
Identify Q Indications received (Permit)	0
NRPM Init Request Counter	0
NRPM Init Confirm Counter	0
NRPM Init Error Counter	0
Identify Q Indications received (Ident ALL)	0

Parameter	Description
Ident Requests Sent	PROFINET I/O specific service
Ident Responses received	Status of the internal status machines in the controller.
(Conflict	
Ident Responses received	
(Forbid)	
Ident Responses received	
(Permit)	
Identify Q Indications	Status of the internal status machines in the controller.
received (Multiple)	
Identify Q Indications	
received (Forbid)	
Identify Q Indications	
received (Permit)	
NRPM Init Request Counter	Counter for special PROFINET I/O services.
NRPM Init Confirmation	Counter for special PROFINET I/O services.
Counter	
NRPM Init Error Counter	Counter for special PROFINET I/O services.
Identify Q Indications	Counter for special PROFINET I/O services.
received (Ident ALL)	

ProSoft Technology, Inc. Page 121 of 150


TCP UDP

IP Information

	IP Information
ask states	
Name	Value
Task State	1
Error Count	2
Last Error	0xC0000119
IP Address	0.0.0.0
Net Mask	0.0.0.0
Gateway	0.0.0.0

Parameter	Description	
Task State	Actual state of the protocol process:	
	0 = Task not initialized	
	1 = Task is running	
	2 = Task initialized	
	3 = Initialization	
Error Counter	Counter for errors.	
Last Error	Last error that occurred.	
IP Address	IP address of the slave device.	
Netmask	Network mask of the slave device.	
Gateway	Gateway address of the Slave device.	

IP Packet Counter




Parameter	Description
Packet Recv TCP	Counter for TCP packets received
Packet Recv UDP	Counter for UDP packets received
Packet Recv ICMP	Counter for ICMP packets received
Packet Recv IP Header Err	Counter for IP packets with errors received
Packet Recv ARP	Counter for ARP packets received
Packet Recv Unknown	Counter for packets of an unknown type received

TCP_UDP Information

TCP_UDP Information
Value
1
2
0xC0080032

Parameter	Description	
Task State	Actual state of the protocol process:	
	0 = Task not initialized	
	1 = Task is running	
	2 = Task initialized	
	3 = Initialization error	
Error Count	Counter for errors.	
Last Error	Last error that occurred.	


T RPC



The T_RPC Extended Diagnosis Information displays PROFINET I/O specific counters.

ProSoft Technology, Inc. Page 123 of 150

T PNIO CMCTL




The T_PNIO_CMCTL Extended Diagnostics Information displays PROFINET I/O specific counters.

T PNIO APCTL

Parameter	Description
Active Application Timers	Number of active software timer.
Received Alarms	Alarms read by the application.
Received Diagnosis Alarms	
Diagnosis entries read by application	
Alarms indicated by application	
Counter for packets that could not	Counts how often packets are sent from the firmware to the
be sent to the application	application and then fails.
Flags	Cached status data.

ProSoft Technology, Inc. Page 124 of 150

T PNIO APCFG



The T_PNIO_APCFG Extended Diagnostics Information displays PROFINET I/O specific parameters.


9.3.7 Tools

The *Packet Monitor*, *I/O Monitor*, and *Process Image Monitor* tools are provided for testing and diagnostic functions. Access to the tools requires a connection between ProSoft fdt Configuration Manager and the PNC driver.

Packet Monitor

The *Packet Monitor* is used for testing and diagnostics. Data packets are self-contained blocks of a defined data length. The packets are used to communicate with the firmware and are exchanged between the application (configuration software) and the firmware in the device. Packets can be sent once or cyclically to the connected device controlled by the user and received packets can be displayed.


Data packets include a packet header and the sent data or may be comprised of a packet header and received data. The packet data can be evaluated by the receiver of the packet and contain the sender and receiver address, data length, ID number, status and error messages, and the command or response code.



DISPLAY MODE switches the representation of data between decimal and hexadecimal. Use the **RESET** button to reset the packet counter.

ProSoft Technology, Inc. Page 126 of 150

Send Packet




Packet Header


Packet elements of the send packet header are displayed. This information is transmitted from the application (configuration software) to the device.

Parameter	Value	Description
Dest	Destination Queue Handle	Contains the identifier of the receiver for the packet
		(destination tasks queue of the firmware).
Src	Source Queue Handle	Contains the identifier of the sender of the packet
		(sending task).
Dest ID	Destination Queue Reference	Contains an identifier for the receiver of unsolicited
		sent packets from the firmware to the application
		(configuration software).
Src ID	Source Queue Reference	Contains an identifier of the sender.
Len	Packet Data Length (in bytes)	Length of the send data.
State	Status/Error Code	Transmits status or error codes to the packet sender.
Cmd	Command/Response Code	Command or respond code.
Ext	Extension	Field for extensions.
Rout	Routing Information Internal value of the firmware.	
ID	Packet identification as unique	Identifies identical data packets among each other.
	number	

1 Select the the receiver (destination task queue) from the **DEST** drop-down list box.




2 Enter the command in the *Cmd* field (request).



The **AUTO INCREMENT ID** checkbox specifies that the identifier should be incremented by one for each newly sent packet.

Send Data pane




This area allows you to enter the send data of the packet that is transmitted from the application (configuration software) to the mailbox of the device. The description of the transmitted data depends on the command or response code.

- The Put Cyclic button specifies that the packet should be sent cyclic.
- The Put Packet button specifies that the packet should be sent once.

Page 130 of 150

Receive Packet



Packet Header

Packet elements of the receive packet header are displayed. This information is transmitted from the device to the application (configuration software).


Parameter	Value	Description	
Dest	Destination Queue Handle	Contains the identifier of the receiver of the	
		packet (destination task queue of the firmware.	
Src	Source Queue Handle	Contains the identifier of the sender of the	
		packet (sending tasking)	
Dest ID	Destination Queue Reference	Contains an identifier for the receiver on	
		unsolicited sent packets from the firmware to	
		the application (configuration software).	
Src ID	Source Queue Reference	Contains an identifier of the sender	
Len	Packet Data Length (in bytes)	Length of the send respectively receive data.	
ID	Packet Identification as Unique	Identifies identical data packets among each	
	Number	other.	
State	Status/Error Code	Transmits status or error codes to the packet	
		sender.	
Cmd	Command/Response Code	Command or response code.	
Ext	Extension	Field for extensions.	
Rout	Routing information	on Internal values of the firmware.	

Receive Data pane

Displays the receiving data of the packet transmitted back from the device to the application (configuration software).

IO Monitor

The *I/O Monitor* is used for testing and diagnostic purposes. It provides a view of the process data image (in bytes) and allows the change of data easily.




Warning: Only change and write output data if you know that it will not cause plant disturbances. All output data written by the I/O Monitor are transmitted at the bus and have an effect on subordinate drives, IO, etc.

- The **COLUMNS** drop-down list changes the number of columns.
- The **DISPLAY MODE** drop-down list allows you to switch the representation of the input and output data between decimal and hexadecimal.
- The **Offset** / **Go** parameters move the indication of the data to the entered offset value.

Enter the output value and click the **UPDATE** button.

Process Image Monitor

This monitor lists devices connected to the PNC controller, as well as configured modules or input or output signals of the devices. This allows you to view the fieldbus structure and the data structure of the device's input and output data transmitted on the bus. Signal data provided to the OPC server is also displayed here.




Parameter	Description
Display Mode	Allows you to display values in the Value column in decimal or hexadecimal
	mode.
	A tree structure is used to display the structure of the devices:
₽ 1	Devices (1)
□ 2	Modules (2)
	Input Data (3)
	Output Data (4)
✓ 4	
?	Shown when the input and output data are not completely read and analyzed.
!	Displayed when input and output data are not valid.
~	Displayed when input and output data are valid.
Туре	Device labeling in the hardware. Describes the module or input or output signals
	configured for the device.
Tag	Device name provided by the hardware (not changeable within PCB for
	PROFINET configuration software) or symbolic name for the modules
	configured for the device for input and output signals (changeable on the
	Configuration > Process Data page)
Value	Displays the valid input and output data values
Last Error	Last error to occur.

ProSoft Technology, Inc. Page 132 of 150


9.3.8 Viewing Alarm Information PLX82.ALARMS

PLX82.ALARM.DeviceAlarms




The Order of devices begins with 0 to 35. The information returned totals 1095 bytes (18 overhead + data.

PLX82.ALARM.LastAlarm



PLX82.ALARM.Message



ProSoft Technology, Inc. Page 133 of 150

9.3.9 EIP Status Data in Upper Memory

The EIP driver has an associated status data area located in the PLX82-EIP-PNC's upper memory. The *Data Map* functionality of the PLX82-EIP-PNC can be used to map this data into the normal user data range of the PLX82-EIP-PNC's database.

Note that all the status values are initialized to zero (0) at power-up, cold boot and during warm boot.

EIP Server Status Data

The following table lists the addresses in upper memory where the PLX82-EIP-PNC stores status data for each EIP server.

EIP Server	Address Range
0	11000 through 11015
1	11016 through 11031
2	11032 through 11047
3	11048 through 11063
4	11064 through 11079

The content of each server's status data area is structured the same. The following table describes the content of each register in the status data area.

Offset	Description	
0 through 1	Connection State	
2 through 3	Open Connection Count	
4 through 5	Socket Read Count	
6 through 7	Socket Write Count	
8 through 15	Peer IP	

EIP Client Status Data

The following table lists the addresses in upper memory the PLX82-EIP-PNC stores general error and status data for each EIP connected and unconnected client.

EIP Client	Address Range
Connected Client 0	12000 through 12109
Connected Client 1	12400 through 12509
Unconnected Client 0	12600 through 12709

The content of each client's status data area is structured in the same way. The following table describes the content of each register in the status data area.

Offset	Description
0	Number of Command Requests
1	Number of Command Responses
2	Number of Command Errors
3	Number of Requests
4	Number of Responses
5	Number of Errors Sent
6	Number of Errors Received
7	Reserved
8	Current Error Code
9	Last Error Code

EIP Client Command List Error Data

The PLX82-EIP-PNC stores a status/error code in upper memory for each command in each EIP client's command list. The following table lists the addresses in upper memory where the gateway stores the command list error data for each EIP client.

EIP Client	Address Range
Connected client 0	7910 through 8009
Connected client 1	8110 through 8209
Unconnected client 0	12810 through 12909

The first word in each client's command list error data area contains the status/error code for the first command in the client's command list. Each successive word in the command error list is associated with the next command in the list. Therefore, the size of the command list error data area depends on the number of commands defined.

The structure of the command list error data area (which is the same for all clients) is displayed in the following table.

Offset	Description	
0	Command #1 Error Code	
1	Command #2 Error Code	
2	Command #3 Error Code	
3	Command #4 Error Code	
4	Command #5 Error Code	
•		
97	Command #98 Error Code	
98	Command #99 Error Code	
99	Command #100 Error Code	

9.3.10 EIP Error Codes

The gateway stores error codes returned from the command list process in the command list error memory region. A word is allocated for each command in the memory area. The error codes are formatted in the word as follows: The least-significant byte of the word contains the extended status code and the most-significant byte contains the status code.

Use the error codes returned for each command in the list to determine the success or failure of the command. If the command fails, use the error code to determine the cause of failure.

Warning: The gateway specific error codes (not EtherNet/IP/PCCC compliant) are returned from within the gateway and never returned from an attached EtherNet/IP/PCCC slave device. These are error codes that are part of the EtherNet/IP/PCCC protocol or are extended codes unique to the PLX82-EIP-PNC. The most common errors for the EtherNet/IP/PCCC protocol are shown in this section.

Local STS Error Codes

Code (Int)	Code (Hex)	Description
0	0x0000	Success, no error
256	0x0100	DST node is out of buffer space
512	0x0200	Cannot guarantee delivery (Link Layer)
768	0x0300	Duplicate token holder detected
1024	0x0400	Local port is disconnected
1280	0x0500	Application layer timed out waiting for response
1536	0x0600	Duplicate node detected
1792	0x0700	Station is offline
2048	0x0800	Hardware fault

Remote STS Error Codes

Code (Int)	Code (Hex)	Description
0	0x0000	Success, no error
4096	0x1000	Illegal command or format
8192	0x2000	Host has a problem and will not communicate
12288	0x3000	Remote node host is missing, disconnected or shut down
16384	0x4000	Host could not complete function due to hardware fault
20480	0x5000	Addressing problems or memory protect rungs
24576	0x6000	Function not allowed due to command protection selection
26872	0x7000	Processor is in Program mode
-32768	0x8000	Compatibility mode file missing or communication zone problem
-28672	0x9000	Remote node cannot buffer command
-24576	0xA000	Wait ACK (1775-KA buffer full)
-20480	0xB000	Remote node problem due to download
-16384	0xC000	Wait ACK (1775-KA buffer full)
-12288	0xD000	Not used
-8192	0xE000	Not used
	0xF0nn	Error code in the EXT STS byte (nn contains EXT error code)

ProSoft Technology, Inc. Page 138 of 150

EXT STS Error Codes

Code (Int)	Code (Hex)	Description	
-4096	0xF000	Not used	
-4095	0xF001	A field has an illegal value	
-4094	0xF002	Fewer levels specified in address than minimum for any address	
-4093	0xF003	More levels specified in address than system supports	
-4092	0xF004	Symbol not found	
-4091	0xF005	Symbol is of improper format	
-4090	0xF006	Address does not point to something usable	
-4089	0xF007	File is wrong size	
-4088	0xF008	Cannot complete request	
-4087	0xF009	Data or file is too large	
-4086	0xF00A	Transaction size plus word address is too large	
-4085	0xF00B	Access denied, improper privilege	
-4084	0xF00C	Condition cannot be generated - resources are not available	
-4083	0xF00D	Condition already exists - resources are already available	
-4082	0xF00E	Command cannot be executed	
-4081	0xF00F	Histogram overflow	
-4080	0xF010	No access	
-4079	0xF011	Illegal data type	
-4078	0xF012	Invalid parameter or invalid data	
-4077	0xF013	Address reference exists to deleted area	
-4076	0xF014	Command execution failure for unknown reason	
-4075	0xF015	Data conversion error	
-4074	0xF016	Scanner not able to communicate with 1771 rack adapter	
-4073	0xF017	Type mismatch	
-4072	0xF018	1171 Gateway response was not valid	
-4071	0xF019	Duplicate label	
-4070	0xF01A	File is open; another node owns it	
-4069	0xF01B	Another node is the program owner	
-4068	0xF01C	Reserved	
-4067	0xF01D	Reserved	
-4066	0xF01E	Data table element protection violation	
-4065	0xF01F	Temporary internal problem	

ProSoft Technology, Inc. Page 139 of 150

EIP Error Codes

Code (Int)	Code (Hex)	Description
-1	0xFFFF	CTS modem control line not set before transmitting
-2	0xFFFE	Timeout while transmitting message
-10	0xFFF6	Timeout waiting for DLE-ACK after request
-11	0xFFF5	Timeout waiting for response after request
-12	0xFFF4	Reply data does not match requested byte count
-20	0xFFEC	DLE-NAK received after request
-21	0xFFEB	DLE-NAK sent after response
-200	0xFF38	DLE-NAK received after request

TCP/IP Interface Error Codes

Error (Int)	Error (Hex)	Description
-33	0xFFDF	Failed to connect to target
-34	0xFFDE	Failed to register session with target (timeout)
-35	0xFFDD	Failed forward open response timeout
-36	0xFFDC	PCCC/Tag command response timeout
-37	0xFFDB	No TCP/IP connection error

Common Response Error Codes

Error (Int)	Error (Hex)	Description
-40	0xFFD8	Invalid response length
-41	0xFFD7	CPF item count is not correct
-42	0xFFD6	CPF address field error
-43	0xFFD5	CPF packet tag invalid
-44	0xFFD4	CPF bad command code
-45	0xFFD3	CPF status error reported
-46	0xFFD2	CPF incorrect connection ID value returned
-47	0xFFD1	Context field not matched
-48	0xFFD0	Incorrect session handle returned
-49	0xFFCF	CPF not correct message number

Register Session Response Error Codes

Error (Int)	Error (Hex)	Description
-50	0xFFCE	Message length received not valid
-51	0xFFCD	Status error reported
-52	0xFFCC	Invalid version

ProSoft Technology, Inc. Page 140 of 150

Forward Open Response Error Codes

Error (Int)	Error (Hex)	Description
-55	0xFFC9	Message length received not valid
-56	0xFFC8	Status error reported

PCCC Response Error Codes

Error (Hex)	Description
0xFFC3	Message length received not valid
0xFFC2	Status error reported
0xFFC1	CPF bad command code
0xFFC0	TNS in PCCC message not matched
0xFFBF	Vendor ID in PCCC message not matched
0xFFBE	Serial number in PCCC message not matched
	0xFFC3 0xFFC2 0xFFC1 0xFFC0 0xFFBF

9.3.11 PNC Status Data in Upper Memory

The PNC driver has an associated status data area located in the PLX82-EIP-PNC's upper memory. The *Data Map* functionality can be used to map this data into the normal user data range of the PLX82-EIP-PNC's database. All the status values are initialized to zero (0) at power-up, cold boot and during warm boot.

PNC Status	Address Range	Description
Number of Input Messages	13000	Total number of write messages to PLC
Internal DPM Input Status Count	13001	Total number of write error messages
Internal DPM Input Status	13002	Error write message status (See tables below)
Number of Output Messages	13004	Total number of read messages from PLC
Internal DPM Output Status		Total number of read error messages
Count	13005	
Internal DPM Output Status	13006	Error read message status (See tables below)
Connection Count	13008	Total number of Connections
Communication Status		Connection Status: 0 (Disconnected) or 1
	13009	(Connected)
Device Status (36)		36 PN Device Status:
	13010	0 or an error number (See tables below)
Input IOPS Information	13082	Input State information (See tables below)
Output IOPS Information	13348 (Not In Use)	Output State information

Internal DPM Input and Output Status Codes

Status Code	Description
0x00000000	No error
0x800B0001	Driver was not correctly initialized during startup or driver is already closed
0x800B0002	Initialization state error. Hardware does not show correct or expected states and
	information after a reset or bootupt
0x800B0003	Driver read state error
0x800B0004	The function is in use by another program instance or application
0x800B0005	General error during download (e.g. bootloader could not be downloaded or started)
0x800B0006	Wrong driver version
0x800B0030	The driver is not loaded/running. Failed to open or start the driver.
0x800B0031	Failed to initialize the driver
0x800B0032	Channel not initialized
0x800B0033	Function call into the driver failed
0x800B0034	Driver was not opened by calling Driver Open function
0x800C0010	Dual port memory not accessible (e.g. board not found, wrong dual port memory content)
0x800C0011	The device is not ready. The system device or communication channel is not working
0x800C0012	The device is not running. The communication channel is not configured
0x800C0013	Watchdog test failed
0x800C0015	Error in handshake flags
0x800C0016	Send mailbox is full
0x800C0017	Send packet timeout
0x800C0018	Receive packet timeout
0x800C0019	No packet available
0x800C001A	Mailbox is too short for the given packet.
0x800C0020	Reset command timeout. The device was not reaching READY state, in the given
	reset timeout, after the application has initiated a reset.
0x800C0021	Communication flag is not set. The Fieldbus protocol stack has no communication with the Fieldbus devices. Either the cable is disconnected, or no other device is connected
	to the wire.
0x800C0022	I/O data exchange failed
0x800C0023	I/O data exchange timeout
0x800C0024	Unknown I/O data exchange mode
0x800C0025	Device function failed
0x800C0026	Memory size differs from the configuration
0x800C0027	Unknown state mode
0x800C0028	The device is accessed either by another application or another instance.
0,000000020	- Driver/device can't be unloaded, open connection to the system device or
	communication channels still active
	- Open channel can't be executed because it is currently used by another application
0x800C0029	Failed to lock the communication channels configuration within the given time.
0x800C002A	Failed to unlock the communication channel configuration within the given time.
0x800C002B	Wait time expires. The device has not acknowledged the new status in time.
0x800C002C	Wait time expires. The function could not clear flag
0x800C002D	Timeout during device / channel initialization
0x800C002E	Wait time expires
0x800C002F	Wait time expires. The device has not acknowledged the new status in time.
0x800C0040	Firmware module download and start failed because a module is already running
0x800C0041	Firmware module download was skipped because the module already exists
0x800C0050	Several configured DMA buffers are insufficient (at least 8 buffers are expected)
0,000000000	octoral configured Divid bullets are mountaint (at least o bullets are expected)

Status Code	Description
0x800C0051	DMA buffers size too small
0x800C0052	DMA buffers size too big
0x800C0053	DMA buffer alignment failed
0x800C0054	I/O process data exchange not allowed
0x800C0055	I/O process data area index not supported
0x800C0056	Failed to set DMA transfer to "ON" within the given wait time
0x800C0057	Failed to set DMA transfer to "OFF" within the given wait time
0x800C0058	The device is in the invalid mode
0x800C0059	Wait time expired during. Device does not signal the expected synchronization handshake flag state

ProSoft Technology, Inc. Page 144 of 150

Device Status bit map

Bit Position	Description
13 to 31	Unused, set to zero
12	Inactive Module present
11	ModuleDiffBlock present
10	Packet too small
9	Diagnosis buffer overwritten
8	Diagnosis buffer overflow
7	Diagnosis disappeared
6	Diagnosis data present for I/O Device
5	I/O Device deactivated
4	I/O Device parameter fault
3	I/O Device invalid response
2	I/O Device configuration fault
1	I/O Device not ready
0	I/O Device does not exist

Input IOPS Information

Bit Position	Description	
0x00	Bad Subslot	
0x20	Bad Slot	
0x40	Bad Device Submodule / module	

10 Reference

10.1 EtherNet/IP Explicit Messaging Server Command Support

The following commands are supported:

Basic Command Set Functions

Command	Function	Definition	Supported in Server
0x00	N/A	Protected Write	X
0x01	N/A	Unprotected Read	X
0x02	N/A	Protected Bit Write	X
0x05	N/A	Unprotected Bit Write	X
0x08	N/A	Unprotected Write	X

PLC-5 Command Set Functions

Command	Function	Definition	Supported in Server
0x0F	0x00	Word Range Write (Binary Address)	X
0x0F	0x01	Word Range Read (Binary Address)	Х
0x0F		Typed Range Read (Binary Address)	Х
0x0F		Typed Range Write (Binary Address)	X
0x0F	0x26	Read-Modify-Write (Binary Address)	
0x0F	0x00	Word Range Write (ASCII Address)	X
0x0F	0x01	Word Range Read (ASCII Address)	Х
0x0F	0x26	Read-Modify-Write (ASCII Address)	

SLC 500 Command Set Functions

Command	Function	Definition	Supported in Server
0x0F	0xA1	Protected Typed Logical Read with Two Address Fields	Х
0x0F	0xA2	Protected Typed Logical Read With Three Address Fields	Х
0x0F	0xA9	Protected Typed Logical Write With Two Address Fields	Х
0x0F	0xAA	Protected Typed Logical Write with Three Address Fields	Х
0x0F	0xAB	Protected Typed Logical Write With Mask (Three Address Fields)

ProSoft Technology, Inc. Page 146 of 150

10.2 Accessing the PLX82-EIP-PNC Internal Memory

The following tables define the relationships of the gateway's internal database to the addresses required in the MSG instructions:

Data Type	Controller Tag Name	Length of Each Element in CIP Message	Array Range for 10000 Element Database
BOOL	BOOLData[]	1	0 to 159999
Bit Array	BITAData[]	4	0 to 4999
SINT	SINTData[]	1	0 to 19999
INT	INT_Data[]	2	0 to 9999
DINT	DINTData[]	4	0 to 4999
REAL	REALData[]	4	0 to 4999

10.2.1 MSG Instruction Type - CIP

Database Address	CIP Integer	CIP Boolean	CIP Bit Array	CIP Byte	CIP DINT	CIP Real
0	Int_data[0]	BoolData[0]	BitAData[0]	SIntData[0]	DIntData[0]	RealData[0]
999	Int_data[999]	BoolData[15984]		SIntData[1998		
1000	Int_data[1000]	BoolData[16000]	BitAData[500]	SIntData[2000]	DIntData[500]	RealData[500]
1999	Int_data[1999]	BoolData[31984]		SIntData[3998		
2000	Int_data[2000]	BoolData[32000]	BitAData[1000]	SIntData[4000]	DIntData[1000]	RealData[1000]
2999	Int_data[2999]	BoolData[47984]		SIntData[5998]		
3000	Int_data[3000]	BoolData[48000]	BitAData[1500]	SIntData[6000]	DIntData[1500]	RealData[1500]
9999	Int_data[9999]	BoolData[159999]		SIntData[9998]		

10.2.2 MSG Instruction Type - PCCC

Database Address	File size 100	Database Address	File size 100
0	N10:0	0	N10:0
999	N19:99	999	N19:99
1000	N20:0	1000	N20:0
1999	N29:99	1999	N29:99
2000	N30:0	2000	N30:0

ProSoft Technology, Inc. Page 147 of 150

10.3 Specifications

10.3.1 Hardware Specifications

Specification	Description	
Power supply	24 Vdc nominal	
	10 Vdc to 36 Vdc allowed	
	Positive, Negative, GND terminals	
Current load	24 Vdc nominal @ 400 mA	
	10 to 36 Vdc @ 610 mA maximum	
Operating temperature	0°C to 50°C (32°F to 122°F)	
Storage temperature	-10°C to 70°C (-14°F to 158°F)	
Relative humidity	5% to 95% RH with no condensation	
Shock	IEC60068-2-27; 15G @ 11ms, 3-axis (Operational)	
	IEC60068-2-27; 30G @ 18ms, 3-axis (Non-operational)	
Vibration	IEC 60068-2-27; 5G @ 10 Hz to 150 Hz	
Dimensions	5.52 x 2.06 x 4.37 in	
$(H \times W \times D)$	14.01 x 5.24 x 11.09 cm	
LED indicators	Configuration (CFG) and Error (ERR) status	
	Power (PWR) and Hardware Fault (FLT)	
	Network Status (NS) EtherNet/IP™ Class I or Class III	
	Connection Status (EtherNet/IP only)	
	Module Status (MS) Module Configuration Status	
	(EtherNet/IP only)	
	Ethernet communication port Link/Activity and 100mbit	
	PROFINET - SYS, SF, BF	
Ethernet Port	10/100Mbit RJ45 connector Electrical isolation 1500 Drams	
	at 50 Hz to 60 Hz for 60 seconds, applied as specified in	
	section 5.3.2 of IEEE 60950: 1991	
	Ethernet Broadcast Storm Resiliency = less than or equal	
	to 5000 [ARM] frames-per-second and less than or equal to	
	5 minutes duration	
Shipped with unit	2.5 mm screwdriver, J180 power connector	

ProSoft Technology, Inc. Page 148 of 150

10.3.2 EtherNet/IP (EIP) Specifications

The EIP server is an ODVA-certified EtherNet/IP implementation.

Specification	Description	
Number of Class 3	5	
server connections		
Supported PLC types	PLC2, PLC5, SLC, CLX, CMPLX	
Class 3 Client	Connected: 2	
connections	Unconnected: 1	
Number of Class 1 I/O	20	
connections		
I/O connection sizes	248 words of input / 248 words of output	
Max RPI time	2 ms (1 connection)	
	8 ms (8 connections)	
CIP services supported	0x4C: CIP Data Table Read	
	0x4D: CIP Data Table Write	
Command List	Support for 100 commands per client, each configurable for command	
	type, IP address, register to/from addressing, and word/bit count.	
Command Sets	PLC-2/PLC-3/PLC5 Basic Command Set	
	PLC-5 Binary Command Set	
	SLC 500 Command Set	

10.3.3 PROFINET (PNC) Specifications

Specification	Description
Driver Type	Class 1 RTC, Class 1 RTA
PROFINET I/O Data	3840 bytes IN, 3840 bytes OUT
Exchange Types	Cyclic Real Time (RT) and Acyclic Data
PROFINET Devices	Max: 36 Max data per device: 2440 bytes IN/OUT

ProSoft Technology, Inc. Page 149 of 150

11 Support, Service & Warranty

11.1 Contacting Technical Support

ProSoft Technology, Inc. is committed to providing the most efficient and effective support possible. Before calling, please gather the following information to assist in expediting this process:

- 1 Product Version Number
- 2 System architecture
- 3 Network details

If the issue is hardware related, we will also need information regarding:

- 1 Module configuration and associated ladder files, if any
- 2 Module operation and any unusual behavior
- 3 Configuration/Debug status information
- 4 LED patterns
- 5 Details about the interfaced serial, Ethernet or Fieldbus devices

North America (Corporate Location)	Europe / Middle East / Africa Regional Office
Phone: +1 661-716-5100	Phone: +33.(0)5.34.36.87.20
ps.prosofttechnology@belden.com	ps.europe@belden.com
Languages spoken: English, Spanish	Languages spoken: English, French, Hindi, Italian
REGIONAL TECH SUPPORT	REGIONAL TECH SUPPORT
ps.support@belden.com	ps.support.emea@belden.com
Latin America Regional Office	Asia Pacific Regional Office
Phone: +52.222.264.1814	Phone: +60.3.2247.1898
ps.latinam@belden.com	ps.asiapc@belden.com
Languages spoken: English, Spanish,	Languages spoken: Bahasa, Chinese, English,
Portuguese	Hindi, Japanese, Korean, Malay
REGIONAL TECH SUPPORT	REGIONAL TECH SUPPORT
ps.support.la@belden.com	ps.support.ap@belden.com

For additional ProSoft Technology contacts in your area, please see: www.prosoft-technology.com/About-Us/Contact-Us

11.2 Warranty Information

For details regarding ProSoft Technology's legal terms and conditions, please see: www.prosoft-technology.com/ProSoft-Technology-Legal-Terms-and-Conditions

For Return Material Authorization information, please see: www.prosoft-technology.com/Services-Support/Return-Material-Instructions