





DF1 Master/Slave to IEC 60870-5-101 Slave Gateway 5102-DFCM3-101S

The DFCM-101S modules are the ideal solution for the many applications where IEC60870-5-101 Slave connectivity can be used to integrate DF1 Master/Slave devices into a system. The 101 gateway is a powerful module designed with Slave support, enabling easy connection to an IEC60870-5-101 Master device. In combination with the DF1 device support, the module provides a very powerful interface to the many DF1 devices which are in use in the industrial marketplace today. Applications for the module are found in most industries, especially Manufacturing, Oil and Gas, Electrical Power and Food Processing.

How to Contact Us: Sales and Support

All ProSoft Technology® products are backed with unlimited technical support. Contact our worldwide Technical Support team directly by phone or email:

Asia Pacific

+603.7724.2080, asiapc@prosoft-technology.com Languages spoken include: Chinese, Japanese, English

Europe - Middle East - Africa

+33 (0) 5.34.36.87.20, support.EMEA@prosoft-technology.com

Languages spoken include: French, English

North America

+1.661.716.5100, support@prosoft-technology.com Languages spoken include: English, Spanish

Latin America (Sales only)

+1.281.298.9109, latinam@prosoft-technology.com Languages spoken include: Spanish, English

Brasil

.

+55-11.5084.5178, eduardo@prosoft-technology.com Languages spoken include: Portuguese, English

DF1 Master/Slave to IEC 60870-5-101 Slave Gateway

5102-DFCM3-101S

The ProLinx DF1 Master/Slave to IEC60870-5-101 Slave Gateway creates a powerful connection between devices on an IEC 101 network and DF1 devices. The module is a stand-alone DIN-rail mounted protocol gateway that provides one IEC 101 Slave configurable serial port and three DF1 Master or Slave configurable serial ports.

The DF1 protocol driver supports Master or Slave implementations of the protocol on each DF1 port. All DF1 ports are individually configurable.

The IEC 60870-5-101 Slave protocol driver supports Slave implementations of the protocol. The serial port is user-configurable, providing a very powerful and flexible host or device interface solution.

DF1 Master/Slave

The DF1 Master/Slave Protocol driver provides extensive support for both Master and Slave implementations of the protocol. The serial port on the gateway is user-configurable to support the DF1 protocol (Master or Slave, Error Checking, Baud rate, etc).

| General Parameters | |
|--------------------------|--|
| Communication parameters | Local Station ID: 0 to 254 |
| | Ports 1 to 3 Baud Rate: 110 to 115K baud |
| | Stop Bits: 1 |
| | Data Size: 8 bits |
| | Parity: None, Even, Odd |
| | RTS Timing delays: 0 to 65535 ms |
| Error Checking | BCC and CRC |
| Miscellaneous | Full hardware handshaking control, |
| | providing radio, smart modem and Multi- |
| | drop support |
| | Floating point data supported |

DF1 Master Protocol Specifications

The ports on the module can be individually configured as Master ports. When configured in master mode, the DFCM module is capable of reading and writing data to remote DF1 devices.

| DF1 Master Driver | |
|-------------------------|---|
| DF1 Modes | Full-Duplex – Master (Module generates |
| | commands) |
| | Half-Duplex – Polling |
| Command List | Up to 100 commands per Master port, |
| | each fully-configurable for function, slave |
| | address, register to/from addressing and |
| | word/bit count |
| Polling of Command List | User-configurable polling of commands, |
| - | including disabled, continuous, and on |
| | change of data (write only) |



DF1 Slave Protocol Specifications

The ports on the module can be individually configured to support the Slave mode of the DF1 protocol. When in slave mode, the module can accept DF1 commands from a master to read/write data stored in the module's internal registers.

| DF1 Slave Driver | |
|-------------------------|---|
| DF1 Modes | Full Duplex – Slave (not peer mode) |
| | Half Duplex – Polled |
| Configurable parameters | Data Table File Start (File N[x] 0 to 999) |
| per slave port | Data Table File Size (1 to 1000 words) |
| | Data Table location in database (0 to 3999) |

IEC 60870-5-101 Slave

The 101S module acts as an input/output module between the IEC 60870-5-101 and other protocols and networks, as well as several proprietary interfaces.

General specifications include:

- User-definable module memory usage
- Storage of IEC time used in module is available in the database
- Protocol implementation conforms to the IEC 60870-5-101 specification with fully configurable parameters
- Priority Queues
- Invalid Bit Monitoring
- Supports Balanced and Unbalanced Mode
- Supports CP24 and CP56 time formats for events
- Event generation configurable per point or data type

| Event generation configurable per point of data type | | |
|--|----------------------------------|--|
| General Parameters | | |
| Communication | Baud Rate: 110 to 19,200 baud | |
| parameters | Stop Bits: 1 or 2 | |
| • | Data Size: 5 or 8 bits | |
| | Parity: None, Even, Odd | |
| | RTS Timing Delays: 0 to 65535 ms | |
| IEC 60870-5-101 Slave | | |
| Configurable Parameters | Data link address length | |
| | Common Address of ASDU length | |
| | Inform. Object Address length | |
| | Select/Operate Timeout | |
| | Event Scan delay | |
| | Use Balanced Mode | |
| | Short Pulse Time | |
| | Long Pulse Time | |
| | Time DB Offset | |

General Specifications

The ProLinx Communication Modules provide connectivity for two or more dissimilar network types. The modules, encased in sturdy extruded aluminum, are stand-alone DIN-rail mounted protocol gateways, providing communication between many of the most widely used protocols in industrial automation today.

Hardware Specifications

.

| Specification | Description |
|-----------------------|-----------------------------------|
| Power Supply | 24 VDC nominal |
| | 18 to 36 VDC allowed |
| | Positive, Negative, GND Terminals |
| | 2.5 mm screwdriver blade |
| Current Load | 500 mA max@ 24 VDC |
| Operating Temperature | –20 to 50°C (–4 to 122°F) |
| Storage Temperature | -40 to 85°C (-40 to 185°F) |

| Cnosification | Description |
|---------------------------|--|
| Specification | Description |
| Relative Humidity | 5 to 95% (non-condensing) |
| Dimensions | Standard: 5.20H x 2.07W x 4.52D in. |
| | (13.2cmH x 5.25cmW x 11.48cmD) |
| | Extended: 5.20H x 2.73W x 4.52D in. |
| | (13.2cmH x 6.934cmW x 11.48cmD) |
| LED Indicators | Power and Module Status |
| | Application Status |
| | Serial Port Activity LED |
| | Serial Activity and Error LED Status |
| Configuration Serial Port | DB-9M RS-232 only |
| _ | No hardware handshaking |
| Ethernet Port (Ethernet | RJ45 Connector |
| modules only) | Link and Activity LED indicators |
| Application Serial Ports | RS-232/422/485 |
| | RS-232 handshaking configurable |
| | RS-422/485 screw termination included |
| Serial Port Isolation | 2500V RMS port signal isolation per UL |
| | 1577 |
| | 3000V DC min. port to ground and port to |
| | logic power isolation |
| Shipped with Each Unit | Mini-DIN to DB-9M serial cables |
| • • | 4 ft RS-232 configuration cable |
| | 2.5mm screwdriver |
| | CD (docs and Configuration utility) |
| | RS-422/485 DB-9 to Screw Terminal |
| | Adaptor (1 or 4, depending on ports) |
| | |

ProSoft Configuration Builder

ProSoft Configuration Builder (PCB) provides a quick and easy way to manage module configuration files customized to meet your application needs. PCB is not only a powerful solution for new configuration files, but also allows you to import information from previously installed (known working) configurations to new projects.

Additional Products

ProSoft Technology offers a full complement of hardware and software solutions for a wide variety of industrial communication platforms.

Visit our web site at http://www.prosoft-technology.com for a complete list of products.

Ordering Information

To order this product, please use the following:

5102-DFCM3-101S DF1 M

DF1 Master/Slave to IEC 60870-5-101 Slave Gateway

To place an order, please contact your local ProSoft Technology distributor. For a list of ProSoft distributors near you, go to http://www.prosoft-technology.com

Distributors:

Place your order by email or fax to:

North American / Latin American / Asia Pacific

orders@prosoft-technology.com,

fax to +1 661.716.5101

Europe

europe@prosoft-technology.com, fax to +33 (0) 5.61.78.40.52

Copyright © ProSoft Technology, Inc. 2000 - 2007. All Rights Reserved

May 03, 2007